MODEL 3660 PIVOT FOLD PLANTER

OPERATOR MANUAL

M0260-01

Rev. 7/16

	2015 Production Year	and on	
Record the model number a	and serial number of your pl	anter along with date purchase	ed:
	Model Number	3660	
	Serial Number		
	Date Purchased		
Monitor Se	rial Number		
Measured !	Pulses Per Mile/Km (Radar	Distance Sensor)	
Measured !	Pulses Per Mile/ Km (Magne	etic Distance Sensor)	

Model 3660 Pivot Fold Planter

SERIAL NUMBER

This manual is applicable to:

The serial number plate is located on the planter frame as shown below. The serial number provides important information about your planter and is needed to obtain correct replacement parts. Always provide model number and serial number to your Kinze Dealer when ordering parts or when contacting Kinze Manufacturing, Inc.





TO THE DEALER

Predelivery service includes assembly, lubrication, adjustment and test. This service helps ensure planter is delivered to retail customer/end user ready for field use.

PREDELIVERY CHECKLIST

Use the following checklist after planter is completely as proper adjustment is made.	sembled. Check off each item as it is found satisfactory or after
☐ Center pivot base mounting and transport wheel spin	dle hex head cap screws torqued to 450 ft-lb (610.1 n-m).
☐ Row units properly spaced and optional attachments	correctly assembled.
☐ Row marker assemblies installed and adjusted at each	h end of the planter.
☐ Vacuum and bulk fill components properly installed (a	s applicable).
☐ All grease fittings in place and lubricated.	
☐ All working parts move freely, bolts are tight, and cott	er pins are spread.
☐ Check all drive chains for proper tension and alignme	nt.
☐ Check for oil leaks and proper hydraulic operation.	
$\hfill \square$ Hydraulic hoses correctly routed to prevent damage.	
☐ Inflate tires to specified air pressure and torque whee	I lug bolts and lug nuts as specified in the manual.
☐ All safety decals correctly located and legible. Replac	e if damaged.
$\hfill \square$ All reflective decals and SMV sign correctly located a	nd visible when the planter is in transport position.
$\hfill \square$ Safety/warning lights correctly installed and working μ	properly.
☐ Paint all parts scratched during shipment or assembly	<i>1</i> .
$\hfill \Box$ All safety lockup devices on the planter and correctly	located.
☐ Auxiliary safety chain properly installed and hardware	torqued to specification.
☐ Vacuum fan PTO-driven pump correctly attached to t leaks (If applicable).	ractor. Oil reservoir filled to capacity and system inspected for
☐ Control box properly installed in tractor. All cables cor	rectly routed and secure.
Planter has been thoroughly checked and to the bes	t of my knowledge is ready for delivery to the customer.
(Signature Of Set-Up Person/Dealer Name/Date)	
OWNER REGISTER	
Name	Delivery Date
Street Address	_Model NoSerial No
City, State/Province	Dealer Name
ZIP/Postal Code	Dealer No.

DELIVERY CHECKLIST

	e the following checklist at time planter is delivered as a reminder of very important information which should be nveyed to retail customer/end user. Check off each item as it is fully explained.
	Check proper operation of vacuum fan, bulk fill fan, and PTO-driven pump (If applicable) with tractor used with planter
	Life expectancy of this or any other machine is dependent on regular lubrication as directed in the Operator Manual
	All applicable safety precautions.
	Along with retail customer/end user, check reflective decals and SMV sign are clearly visible with planter in transport position and attached to tractor. Check safety/warning lights are in working condition. Tell retail customer/end user to check federal, state/provincial, and local regulations before towing or transporting on a road or highway.
	Give Operator Manual, Parts Manual, and all Instruction Sheets to retail customer/end user and explain all operating adjustments.
	Read warranty to retail customer/end user.
	Complete Warranty and Delivery Report form.
,	gnature Of Delivery Person/Dealer Name/Date)
Al	FTER DELIVERY CHECKLIST
Th	e following is a list of items we suggest to check during the first season of use of the equipment.
	Check planter performance with retail customer/end user.
	Check performance of vacuum or mechanical seed metering system with retail customer/end user.
	Review importance of proper maintenance and adherence to all safety precautions with retail customer/end user.
	Check for parts that may need to be adjusted or replaced.
	Check all safety decals, reflective decals, and SMV sign are correctly located as shown in the Parts Manual and that decals are legible. Replace if damaged or missing.
	Check safety/warning lights are working properly.
(Si	gnature Of Follow-Up Person/Dealer Name/Date)

All registrations must be submitted online at "business.kinze.com" within 5 business days of delivery.

Retain a copy of this form for auditing purposes.

Tear Along Perforation

MACHINE OPERATION	Row Marker Adjustments2-25
To The Owner	Row Marker Even-Row Length Adjustment 2-20
Warranty1-2	Offset Hitch Adjustment
General Information	Point Row Clutches
Tractor Hydraulic Requirements	Auxiliary Hydraulic Option
Specifications	Rear Trailer Hitch
General Safety Rules1-4	Field Test
Safety Signs And Decals	Field Check Seed Population
Safety Precautions1-5	Determining Pounds Per Acre (Brush-Type Meter) 2-3
	Determining Bushels Per Acre2-3
MACHINE OPERATION	Field Check Granular Chemical Application2-32
Planter Lift Safety Lockup2-1	
Row Marker Safety Lockup	ROW UNIT OPERATION
Tongue Safety Pin	Planting Depth
Transport Latch Locking Pin2-2	"V" Closing Wheel Adjustment (Rubber or Cast Iron)3-
Initial Preparation2-3	Closing Wheel Shield (Rubber or Cast Iron
Tractor Mounted PTO Pump And Oil Cooler Option2-4	"V" Closing Wheels)
Planter Mounted PTO Pump And Oil Cooler Option 2-5	Drag Closing Attachment
Tractor Requirements2-5	Covering Discs/Single Press Wheel Adjustment
Tractor Preparation and Hookup	Seed Hoppers
Level Planter	Seed Meter Drive Release
Ridge Planting	Row Unit Extension Brackets
Control Console Operation	Row Unit Chain Routing
Hydraulic Seed Rate Drive	Quick Adjustable Down Force Springs Option (Standard or Heavy Duty)
Hall Effect Sensor (Hydraulic Drive Only)	Interplant Push Row Unit Clutch Sprocket3-6
Hydraulic Weight Transfer Toolbar	Interplant Push Row Unit Vacuum Hose Shutoff 3-
Ag Leader Electric Clutches2-11	Interplant Push Row Unit Lockups3-
Transport to Field Sequence	General Planting RATE Information
Field Operation2-14	Brush-Type Seed Meter
Planting Speed2-14	Finger Pickup Seed Meter
Field to Transport Sequence	Vacuum Settings
Vacuum System2-17	Seed Meter Cleanout
Digital Vacuum Readout	Additives
Vacuum Fan Motor Valve Block Assembly	Frame Mounted Coulter (Pull Row)
Analog Vacuum or Pressure Gauge	Residue Wheels (Frame Mounted Coulter)
Bulk Fill System	Row Unit Mounted Disc Furrower (Pull Row)3-20
Bulk Fill Entrainer Access	Row Unit Mounted Bed Leveler (Pull Row)
Bulk Fill Tanks - Clean Out	Bayer Fluency Agent
Bulk Fill Scale Package Option	Row Unit Mounted Residue Wheel
Ag Leader Integra Display	Spiked Closing Wheel
Ag Leader Monitoring Control Package	Row Unit Mounted No Till Coulter
Auxiliary Work Lights Package	Coulter Mounted Residue Wheels
Kinze ISOBUS Option	Granular Chemical Hopper and Drive
Row Marker Operation	Spring Tooth Incorporator
Row Marker Speed Adjustment	Granular Chemical Banding Options
Even-Row Push Row Unit	Granular Chemical Bander Shield 3-20

FERTILIZER	Pressure Reducing Relief Valve5-27
Double Disc Fertilizer Opener	Row Marker Bearing Lubrication or Replacement5-28
Notched Single Disc Opener	Wheel Bearing Repack or Replacement 5-29
Residue Wheel Attachment for Notched Single Disc	Pneumatic Down Pressure Air Compressor Tank 5-35
Fertilizer Opener	Fertilizer Check Valve Cleaning and Repair5-36
Depth/Gauge Wheel Attachment for Notched Single	Piston Pump Storage5-36
Disc Fertilizer Opener	ISOBUS Implement Cable
Liquid Fertilizer Attachment	ISOBUS CAN Jumper Cable
Liquid Fertilizer Attacriment4-6	Product Control Module Cable5-53
LUBRICATION AND MAINTENANCE	Implement Switch Extension Cable 5-54
Lubrication	Section Adapter Cable - 12 Row
Lubrication Symbols	Section Adapter Cable - 16 Row
Sealed Bearings	Clutch Cable - 12 Row5-56
Bushings	Clutch Cable - 16 Row5-57
Center Post	
Liquid Fertilizer Piston Pump5-4	TROUBLESHOOTING
Crankcase Oil Level	Bulk Fill6-1
PTO Pump Shaft Coupling (Tractor Driven PTO Pump	Closing Wheel
and Oil Cooler Option)	Lift Circuit Troubleshooting 6-2
Grease Fittings5-6	Piston Pump6-3
Mounting Bolts and Hardware	PTO Pump Drive and Oil Cooler Option6-3
Tractor Driven PTO Pump and Oil Cooler Option 5-14	Rotation Circuit
Finger Pickup Seed Meter Inspection/Adjustment5-15	Row Marker Operation
Cleaning Finger Pickup Seed Meter For Storage 5-16	Seed Meter (Brush-Type)
Brush-Type Seed Meter Maintenance 5-17	Seed Meter (Finger Pickup)6-8
Cleaning Brush-Type Seed Meter For Storage 5-18	Solenoid Valve
Vacuum Manifold Maintenance	Tongue Cylinder Circuit
Vacuum Seed Meter Maintenance5-19	Vacuum Seed Meter6-6
Seed Meter Cleanout5-19	Wing Lock Cylinder Circuit 6-10
Drag Closing Attachment5-20	
Gauge Wheel Adjustment	
Gauge Wheel Arm Bushing and/or Seal Replacement 5-21	
Gauge Wheel Arm Pivot Spindle Replacement 5-21	
15" Seed Opener Disc Blade/Bearing Assembly5-22	
Seed Tube Guard/Inner Scraper	
Frame Mounted Coulter	
Residue Wheels (For Use With Frame Mounted Coulter)	
Row Unit Mounted Disc Furrower	
Row Unit Mounted Bed Leveler	
Row Unit Mounted No Till Coulter	
Spiked Closing Wheel	
Coulter Mounted Residue Wheels	
Row Unit Mounted Residue Wheel 5-26	
Granular Chemical Attachment	
Spring Tooth Incorporator	

Pressure Reducing Relief Valve
Row Marker Bearing Lubrication or Replacement5-28
Wheel Bearing Repack or Replacement 5-29
Pneumatic Down Pressure Air Compressor Tank 5-35
Fertilizer Check Valve Cleaning and Repair5-36
Piston Pump Storage5-36
ISOBUS Implement Cable
ISOBUS CAN Jumper Cable
Product Control Module Cable
Implement Switch Extension Cable 5-54
Section Adapter Cable - 12 Row
Section Adapter Cable - 16 Row
Clutch Cable - 12 Row5-56
Clutch Cable - 16 Row5-57
UBLESHOOTING
Bulk Fill
Closing Wheel
Lift Circuit Troubleshooting
Piston Pump6-3
PTO Pump Drive and Oil Cooler Option 6-3
Rotation Circuit6-4
Row Marker Operation6-4

Kinze Manufacturing, Inc. thanks you for your patronage. We appreciate your confidence in Kinze farm machinery. Your Kinze planter has been carefully designed to provide dependable operation in return for your investment.

This manual has been prepared to aid you in the operation and maintenance of the planter. It should be considered a permanent part of the machine and remain with the machine when you sell it.

It is the responsibility of the user to read and understand the Operator Manual in regards to safety, operation, lubrication and maintenance before operation of this equipment. It is the user's responsibility to inspect and service the machine routinely as directed in the Operator Manual. We have attempted to cover all areas of safety, operation, lubrication and maintenance; however, there may be times when special care must be taken to fit your conditions.

Throughout this manual the symbol and the words **DANGER**, **WARNING**, and **CAUTION** are used to call attention to safety information that if not followed, will or could result in death or injury. **NOTICE** and **NOTE** are used to call your attention to important information. The definition of each of these terms follows:



DANGER Indicates a hazardous situation which, if not avoided, will result in death or serious injury.



WARNING Indicates a hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION, used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE is used to address practices not related to personal injury.

NOTE: Special point of information or machine adjustment instructions.



Improperly operating or working on this equipment could result in death or serious injury. Read and follow all instructions in Operator Manual before operating or working on this equipment.



Some photos in this manual may show safety covers, shields, or lockup devices removed for visual clarity. NEVER OPERATE OR WORK ON machine without all safety covers, shields, and lockup devices in place as required.

NOTE: Photos in this manual may be of prototype machines. Production machines may vary in appearance.

NOTE: Some photos and illustrations in this manual show optional attachments installed. Contact your Kinze Dealer for purchase of optional attachments.

WARRANTY

The Kinze Limited Warranty for your new machine is stated on the retail purchaser's copy of the Warranty And Delivery Receipt form. Additional copies of the Limited Warranty can be obtained through your Kinze Dealer.

Warranty, within the warranty period, is provided as part of Kinze's support program for registered Kinze products which have been operated and maintained as described in this manual. Evidence of equipment abuse or modification beyond original factory specifications will void the warranty. Normal maintenance, service and repair is not covered by Kinze warranty.

To register your Kinze product for warranty, a Warranty And Delivery Receipt form must be completed by the Kinze Dealer and signed by the retail purchaser, with copies to the Dealer, and to the retail purchaser. Registration must be completed and submitted to Kinze Manufacturing, Inc. within 5 business days of delivery of the Kinze product to the retail purchaser. Kinze Manufacturing, Inc. reserves the right to refuse warranty on serial numbered products which have not been properly registered.

If service or replacement of failed parts which are covered by the Limited Warranty are required, it is the user's responsibility to deliver the machine along with the retail purchaser's copy of the Warranty And Delivery Receipt to the Kinze Dealer for service. Kinze warranty does not include cost of travel time, mileage, hauling or labor. Any prior arrangement made between the Dealer and the retail purchaser in which the Dealer agrees to absorb all or part of this expense should be considered a courtesy to the retail purchaser.

Kinze warranty does not include cost of travel time, mileage, hauling, or labor.

GENERAL INFORMATION

The Model 3660 Twin-Line planter is available with vacuum or mechanical meters, conventional hoppers or bulk fill, Interplant, liquid fertilizer, and various other options. Contact your Kinze Dealer for available options and configurations. To obtain the most recent version of your publication, please contact your Kinze dealer.



Model 3660 12 Row Bulk Fill Planter

Information used in these instructions was current at time of printing. However, due to Kinze's ongoing product improvement, production changes may cause your machine to appear slightly different in detail. Kinze Manufacturing, Inc. reserves the right to change specifications or design without notice and without incurring obligation to install the same on machines previously manufactured.

Right hand (R.H.) and left hand (L.H.), as used throughout this manual, are determined by facing direction machine travels in use unless otherwise stated.

Specification	Conventional Hoppers			
Number of Rows	12R N 30 16R N 30			
Weight Empty (Mechanical)	15,040 lb (6823 kg) 18,460 lb (8374 kg) - 19,100 lb (8663.6			
Weight Empty (Vacuum)	15,450 lb (7008 kg) 18,400 lb (8347 kg)			
Transport Height	11' 11" (3.6M) 11' 11" (3.6M)			
Planting Length	23' 9" (7.2M) 26'3" (8M)			
Transport Length	39' 2" (12M) 49'2" (15M)			
Planting Width	32' 11" (10M) 42'11" (13.1M)			
Transport Width	11' 2" (3.4M) 11'2" (3.4M)			
Seed Capacity	1.75 bu. (Vacuum / Hopper); 1.90 bu. (Mechanical / Hopper)			
Transport Tire Size	Four 41" x 11" R22.5 radial load range 'H' tubeless rib implement.			
Field Tire Size	7.50" x 20" 8 ply tubeless rib implement tires.			
Field Lift	Two master center rockshaft/four wing wheel slave rephasing cylinders.			
Row Markers	Independently controlled, three stage, low profile, w/disk blade depth bands.			

Specification	Bulk Fill			
Number of Rows	12R N 30	16R N 30		
Weight Empty (Mechanical)	17,120 lb (7766 kg) - 17,450 lb (7916 kg) 20,020 lb (9081 kg) - 20,400 lb (9254 kg)			
Weight Empty (Vacuum)	17,120 lb (7766 kg) - 17,450 lb (7916 kg) 20,020 lb (9081 kg) - 20,400 lb (9254 l			
Transport Height	12' 11" (4M) 12'11" (4M)			
Planting Length	23' 9" (7.2M) 26'3" (8M)			
Transport Length	39' 2" (12M)	49'2" (15M)		
Panting Width	32' 11" (10M)	42'11" (13.1M)		
Transport Width	11' 2" (3.4M)	11'2" (3.4M)		
Seed Capacity	110 bu.			
Bulk Fill Fill Height	8' 5" (2.6M)			
(planting position)				
Transport Tire Size	Four 41" x 11" R22.5 radial load range 'H' tubeless rib implement.			
Field Tire Size	7.50" x 20" 8 ply tubeless rib implement.			
Field Lift	Two master center rockshaft/four wing wheel slave rephasing cylinders.			
Row Markers	Independently controlled, three stage, low profile, w/disk blade depth bands.			

TRACTOR HYDRAULIC REQUIREMENTS

Configuration	No Optional Pumps		Tractor Mounted Pump ²		Planter Mounted Pump ²	
Mechanical Meter	3 SCV	20 gpm min.				
Vacuum Meter ¹	4 SCV	40 gpm min.	3 SCV	25 gpm min.		
Bulk Fill (with Mechanical Meter) ³	4 SCV	30 gpm min.	3 SCV	20 gpm min.		
ASD (with Vacuum) ³	5 SCV	50 gpm min.	4 SCV	40 gpm min.	3 SCV	25 gpm min.

¹External case drain required for vacuum hydraulic circuits when no optional pumps are used.

 $^{^2}$ Pump PTO Requirements: Tractor mounted - 1000 rpm, 1%" diameter shaft. Planter mounted - 1000 rpm, 1¾" diameter shaft.

³Tractor Horsepower Requirement: 225 horsepower or greater class tractor is required to effectively operate a fully optioned (Bulk Fill, Interplant, Vacuum) 3660 planter.

- 1. Read and understand instructions provided in this manual and warning labels. Review these instructions frequently!
- 2. This machine is designed and built with your safety in mind. Do not make any alterations or changes to this machine. Any alteration to design or construction may create safety hazards.
- 3. A large portion of farm accidents happen from fatigue or carelessness. Safe and careful operation of tractor and planter will help prevent accidents.
- 4. Never allow planter to be operated by anyone unfamiliar with operation of all functions of the unit. Operators must read and thoroughly understand all instructions given in this manual before operating or working on equipment.
- 5. Be aware of bystanders, particularly children! Always look around to make sure it is safe to start tow vehicle engine or move planter. This is particularly important with higher noise levels and quiet cabs, as you may not hear people shouting.
- 6. Make sure planter weight does not exceed towing capacity of tractor, or bridge and road limits. This is critical to maintain safe control and prevent death or injury, or property and equipment damage.
- 7. Never ride or allow others to ride on planter.
- 8. Store planter in an area away from human activity. DO NOT permit children to play on or around the stored unit.
- 9. Keep hands, feet, and clothing away from moving parts. Do not wear loose-fitting clothing which may catch in moving parts.
- 10. Always wear protective clothing, shoes, gloves, hearing, and eye protection applicable for the situation.
- 11. Do not allow anyone to stand between tongue or hitch and towing vehicle when backing up to planter.
- 13. Prevent electrocution, other injuries, or property and equipment damage. Watch for obstructions such as wires, tree limbs, etc. when operating machine. Be aware of clearances during turns and when folding/unfolding planter.
- 14. Reinstall all guards removed for maintenance activities. Never leave guards off during operation.

- 15. Use of aftermarket hydraulic, electric, or PTO drives may create serious safety hazards to you and people nearby. If you install such drives, follow all appropriate safety standards and practices to protect you and others near this planter from injury.
- 16. Follow all federal, state/provincial, and local regulations when towing farm equipment on a public highway. Use safety chain (not an elastic or nylon/plastic tow strap) to retain connection between towing and towed machines in the event of primary attaching system separation.
- 17. Make sure all safety/warning lights, SMV sign, and reflective decals are in place and working properly before transporting the machine on public roads.
- 18. Limit towing speed to 15 MPH. Tow only with farm tractor of a minimum 90 HP. Allow for unit length when making turns.
- 19. Reduce speed prior to turns to avoid the risk of overturning. Always drive at a safe speed relative to local conditions and ensure your speed is slow enough for a safe emergency stop.
- 20. Chemical application is often an integral part of planting. Follow label instructions for proper chemical mixing, handling and container disposal methods.
- 21. Be familiar with safety procedures for immediate first aid should you accidentally contact chemical substances.
- 22. Use the proper protective clothing and safety equipment when handling chemicals.
- 23. Chemicals are supplied with Material Safety Data Sheets (MSDS) that provide full information about the chemical, its effects on exposure, and first aid needs in the event of an emergency. Keep your MSDS file up-to-date and available for first responders in case of emergency.
- 24. When servicing ground engaging components such as opening disks and firming points, use special care to avoid points and edges worn sharp during use.
- 25. Use professional help if you are unfamiliar with working on hydraulic systems. Pressurized hydraulic fluid can penetrate body tissue and result in death, serious infection, or other injuries.

Following are some common hazard warnings associated with this equipment. Pay close attention to all safety, operating, and maintenance information in this manual and decals applied to your equipment.



DANGER!

Contacting or coming close to power lines or other high energy sources will cause death or serious injury. Keep away from power lines or high energy sources at all times.



WARNING

Improperly operating or working on this equipment could result in death or serious injury. Read and follow all instructions in Operator Manual before operating or working on this equipment.



WARNING

Falling equipment can cause death or serious injury. Install all lockup devices or lower planter to ground before working on equipment.



WARNING

Explosive separation of rim and tire parts can cause death or serious injury. Overinflation. rim and tire servicing, improper use of rims and tires, or worn or improperly maintained tires could result in a tire explosion.

SAFETY SIGNS AND DECALS



WARNING


All safety/warning lights, reflective decals, and SMV sign must be in place and visible before transporting machine on public roads or death, serious injury, and damage to property and equipment may result. Check federal, state/provincial, and local regulations before transporting equipment on public roads.

Safety signs and decals are placed on the machine to warn of hazards and provide important operating and maintenance instructions. Information on these signs are for your personal safety and the safety of those around you. FOLLOW ALL SAFETY INSTRUCTIONS!

- Keep signs clean so they can be easily seen. Wash with soap and water or cleaning solution as required.
- Replace safety signs if damaged, painted over, or missing.
- Check reflective decals and SMV sign periodically. Replace if they show any loss of of reflective properties.
- Clean machine surface thoroughly with soap and water or cleaning solution to remove all dirt and grease when replacing decals.

NOTE: Safety sign and decal locations are shown in the Parts Manual for this machine.


NOTE: Style and locations of SMV sign, reflective decals, and safety/warning lights conform to ANSI/ASABE S279.14 JUL 2008 and ANSI/ASABE S276.6 JAN 2005.




PLANTER LIFT SAFETY LOCKUP



Uncontrolled machine movement can crush or cause loss of control resulting in death, serious injury, or damage to property and equipment. Install all safety lockup devices before working under or transporting this equipment.







Safety lockup in transport/maintenance position

Planter lift safety lockup is installed between center post and lift cylinder. It is held in place by a clevis pin near the base of the lift cylinder rod. Remove safety lockup and store on hose take-up for field operation.


ROW MARKER SAFETY LOCKUP



Row marker can lower at any time and could cause death or serious injury. Stay away from row markers! Install safety lockup device when not in use.

Always install row marker lockups when working or transporting planter.

Connect chain between marker stand and second stage of marker assembly.




Row marker safety lockup installed

A WARNING

Uncontrolled movement of equipment can cause loss of control and could result in death, serious injury, or damage to property and equipment. Install all safety pins before transporting equipment.

TONGUE SAFETY PIN







Tongue safety pin stored for field operation

Never transport planter without installing tongue safety pin. Tongue safety pin prevents tongue cylinder from retracting should hydraulic failure occur or a sudden stop be made when transporting planter.

Secure safety pin in hitch with snap pin. Remove tongue safety pin and store in bracket on transport latch post at center of planter for field operation.

TRANSPORT LATCH LOCKING PIN



Transport latch locking pin stored



Transport latch locking pin installed

Never transport planter without installing transport latch locking pin. Transport latch locking pin prevents latch bar from disengaging and allowing planter frame to swing away.

Remove transport latch locking pin and store in location provided on latch post for field operation.

INITIAL PREPARATION

Following information is general in nature to aid in preparation of tractor and planter for use, and to provide general operating procedures. Operator experience, familiarity with the machine, and the following information should combine for efficient planter operation and good working habits.



Improperly operating or working on this equipment could result in death or serious injury. Read and follow all instructions in Operator Manual before operating or working on this equipment.



Folding or towing planter with outer transport wheel on left side of machine removed can cause death, serious injury, or damage to property and equipment. Tipping may occur because of narrow wheel base. Outer transport wheel on left side of machine is shipped removed on non-bulk fill planters (not bolted on) to allow narrower width truck shipment. DO NOT REMOVE THIS ASSEMBLY AFTER PLANTER IS ASSEMBLED FOR USE.



Loose transport wheel lug bolts can result in wheel separation from planter and cause death, serious injury, and damage to property and equipment. Torque transport wheel 5/8"- 18 lug bolts to 180 ft-lb (244 N-m) before operating planter for the first time and periodically after.



Explosive separation of rim and tire can cause death or serious injury. Overinflation, rim and tire servicing, improper use of rims and tires, worn, or improperly maintained tires could result in a tire explosion.


- 1. Torque transport wheel %"- 18 lug nuts to 180 ft-lb (244 N-m).
- 2. Inflate tires to the following specifications:

Transport (center section) 255-70R 22.5 ("224" rim) 75 psi (517.1 kPa) recommended/75 psi (517.1 kPa) max.

Transport (center section) 255-70R 22.5" ("276" rim) 75 psi (517.1 kPa) recommended/100 psi (689.4 kPa) max.

Ground drive (wings) 7.50" x 20" 40 psi (275.7 kPa)

Liquid fertilizer piston pump 7.60" x 15" 40 psi (275.7 kPa)



Tire locations


- 3. Lubricate planter and row units following instructions in Lubrication and Maintenance section of this manual.
- 4. Check all row unit drive chains for proper tension, alignment, and lubrication.

TRACTOR MOUNTED PTO PUMP AND OIL COOLER OPTION

Tractor driven PTO pump and oil cooler option is for tractors with less than required hydraulic output needed to operate hydraulic-driven vacuum fan and other planter hydraulic requirements.

A 1000 RPM PTO is required to operate PTO-driven hydraulic pump.

Option consists of a 1%"-21 or 13/4"-20 spline,13.5 GPM 2000 PSI tractor mounted pump, 10 gallon capacity hydraulic reservoir, 15 GPM-rated oil cooler, spin-on 10-micron oil filter, and required hydraulic valves and fittings.



Hydraulic reservoir assembly



Vacuum fan assembly

NOTICE

Clean and grease PTO shaft coupling with high-pressure industrial coupling grease (Chevron coupling grease or equivilant) meeting AGMA CG-1 and CG-2 Standards each time driveshaft is installed or premature wear and equipment failure can occur.

Chevron® trademark is owned by Chevron Products Company. AGMA is the acronym for American Gear Manufacturers Association.



Tractor mounted PTO pump (1%" spline PTO pump shown)


Planter mounted PTO pump drive with oil coolers option is for tractors with less than required hydraulic output needed to operate hydraulically driven vacuum and pressure fans and other planter hydraulic requirements.

A 1¾"-20 spline 1000 rpm PTO is required to operate planter mounted hydraulic pumps.

Option consists of a PTO driveshaft, 13.5 gpm/2000 psi two-section pump, 10 gallon hydraulic oil reservoir, two oil coolers, two spin-on 10-micron oil filters, and required valves and fittings.

Flow control valve - Bulk fill fan (opposite side)

M0260-01



PTO pumps and reservoir assembly




Bulk fill fan assembly

NOTICE

Clean and grease PTO shaft coupling with high-pressure industrial coupling grease (Chevron coupling grease or equivilant) meeting AGMA CG-1 and CG-2 Standards each time driveshaft is installed or premature wear and equipment failure can occur.

Chevron® trademark is owned by Chevron Products Company. AGMA is the acronym for American Gear Manufacturers Association.



Vacuum fan assembly

TRACTOR REQUIREMENTS

Consult your dealer for information on horsepower requirements and tractor compatibility. Requirements vary with planter options, tillage, and terrain.

A 12 volt DC electrical system is required on all sizes.

TRACTOR PREPARATION AND HOOKUP

- 1. Adjust tractor drawbar 13-17 inches above ground with hitch pin hole directly below PTO shaft center line. Make sure drawbar is in a stationary position.
- Install control console on tractor in a convenient location within easy reach of operator and close to hydraulic controls. Mount control console securely and route power cord to power source. Control console operates on 12 volt DC only. If two 12 volt batteries are connected in series, ALWAYS make power connection on battery grounded to tractor chassis.
 - If two 6 volt batteries are connected in series, make sure power connection provides 12 volt DC across positive terminal on one battery and negative terminal of second battery.
- 3. Back tractor to planter and connect with 1½" 1½" diameter hitch pin. If tractor is not equipped with a hitch pin locking device, make sure hitch pin is secured with a locking pin or cotter pin.



Planter/safety chain hookup to tractor



Optional 2-point hitch

NOTE: DO NOT install safety chain using clevis mounting hardware. Safety chain MUST be installed separately.

4. Safety chain must be used to keep planter and tractor connected in case of a hitch pin/drawbar failure. Attach safety chain at an unused clevis mounting hole on the planter hitch. Torque hardware to 840 ft-lb (1138.8 N-m).

NOTE: A 2-Point Hitch Option converts planter from drawn to semi-mounted and is available for use with Category 3N or 3 three-point hitch designs. Safety chain is not used with 2-point hitch.



Pressurized hydraulic fluid can penetrate body tissue and result in death, serious infection, or other injuries. Fluid injected under skin must be IMMEDIATELY removed by a surgeon familiar with this type of injury. Make sure connections are tight and hoses and fittings are not damaged before applying system pressure. Leaks can be invisible. Keep away from suspected leaks. Relieve pressure before connecting or disconnecting tractor, searching for leaks, or performing any system maintenance.

NOTICE

Wipe hose ends to remove any dirt before connecting couplers to tractor ports or contamination may cause equipment failure.

5. Connect hydraulic hoses to tractor ports in a sequence familiar and comfortable to the operator.

NOTICE

Connect hydraulic motor case drain to a case drain return line with zero PSI on tractor. Failure to connect to a return with zero PSI will cause hydraulic motor shaft seal damage. DO NOT connect hydraulic motor case drain to a SCV outlet or motor return circuit connection. Contact tractor manufacturer for specific details on "zero pressure return".

NOTICE

Always connect hydraulic motor return hose to tractor motor return port. Do not connect to tractor SCV unless through a motor spool or hydraulic motor failure can occur. If a motor return port is not available on the tractor, the SCV controlling the bulk fill system MUST be in the float position before planter is moved in planting or field raised position when bulk fill system is not in use.

PLANTER TO TRACTOR HYDRAULIC CONNECTIONS				
Color/Label	Machine Function	Hose Size	Function	
Red AA	Field Lift	1/2"	Pressure	
Red BB		1/2"	Return	
Blue AA	Planter Fold & Row Marker	3/8"	Return	
Blue BB		3/8"	Pressure	
Black RR	Seed Rate Hydraulic Drive	3/4"	Return	
Black PP	(Vacuum)	1/2"	Pressure	
Black RR	Seed Rate Hydraulic Drive (Mechanical)	1/2"	Return	
Black PP		3/8"	Pressure	
Green RR	Vacuum Fan	3/4"	Return	
Green PP		1/2"	Pressure	
Orange CD		3/8"	Case Drain	
Yellow RR	Bulk Fill System Pressure Fan	3/4"	Motor Return	
Yellow PP		1/2"	Pressure	
Orange CD		3/8"	Case Drain	

NOTE: Set adjustable flow outlet (SCV) to full flow position.

For tractors not equipped with a method for finite adjustment of hydraulic flow, Flow Control Needle Valve Kit G1K426 is available from Kinze Repair Parts through your Kinze Dealer.



G1K426 needle valve kit

Connect ASABE Standards 7 terminal connector for safety/warning lights on planter to ASABE Standards
receptacle on tractor. If your tractor is not equipped with an ASABE Standards receptacle, check with your tractor
manufacturer for availability. Check warning lights on planter work in conjunction with warning lights on tractor.

NOTE: A 12 volt battery connection is required to power the vacuum fan digital gauge. Connect "red" wire to positive (+) battery terminal and "black" wire to negative (-) battery terminal.







Jack in storage position

7. Raise jack stand and remount horizontally on storage bracket on opposite side of hitch.

LEVEL PLANTER

Lateral adjustment is maintained by tire pressure. Check tires are inflated to specification.

Front and rear level adjustment is maintained by hitch clevis position unless tractor drawbar is adjustable for height. Planter frame and row unit parallel arms must be level for proper planter and row unit operation. Bottom of toolbar should be 20" to 22" from planting surface.

1. Lower planter to planting position and check planter is level front to rear. Go to step 2 if hitch is too high or low.



Level planter toolbars

NOTE: DO NOT install safety chain using clevis hardware. Move safety chain location if necessary.

2. Remove clevis hitch hex head cap screw and lock nut using a torque wrench. Replace if off-torque is below 75 ft-lb (101.6 N-m) or there is corrosion or damage.

NOTE: Clevis must be free to move on hitch. DO NOT OVERTIGHTEN hardware.

3. Align clevis to hitch holes at new location and install hex head cap screw and lock nut. Tighten lock nut until threads are fully engaged and hex head cap screw and lock nut are firmly against hitch bracket.

NOTE: On planters with push row units and no till coulters, uplift from down force springs or air springs in pneumatic down pressure system may cause wings to rise slightly in planting position. Problem may be compounded if static pressure is trapped in planter's hydraulic lift system which can cause wing cylinders to extend slightly. Operating tractor's hydraulic system in float position or moving tractor's hydraulic lever to float position briefly to relieve pressure will help maintain proper toolbar height.


4. Field check planter.

Field and actual planting conditions dictate which transport wheel setting to use so row unit parallel arms are parallel with ground. It may be necessary to lower ground drive wheels to ensure level lateral toolbar operation if transport wheels are set in one of the two lower sets of holes. Make a field check when planter is fully loaded with seed, granular chemicals, fertilizer, etc. to be sure wings are level with center frame. If wings are not level with center frame, drive wheels and/or transport wheels can be raised or lowered in wheel arms to increase or decrease planter toolbar height. Raise hitch to ensure level operation.


NOTICE

Component interference can damage equipment. Check clearance between tires and drill shaft U-joint when using top hole setting.

NOTE: To allow adequate drive force after lowering ground drive wheels, it may be necessary to lower contact drive wheel arms to lower sets of holes in wheel modules and lower down pressure springs to lower mounting rods on wheel modules.



Transport wheel adjustment



Model 3660



Field/wing wheel adjustment

RIDGE PLANTING

Move drive and transport wheels 2" or 4" to lower mounting holes in wheel arms when ridge planting to increase planter toolbar height. Raise hitch height to ensure level operation.

CONTROL CONSOLE OPERATION

Tractor's hydraulic system and planter control console are used to raise and lower planter, rotate frame, extend and retract tongue, lock and release wings, and operate row markers.



DANGER!

Contacting or coming close to power lines or other high energy sources will cause death or serious injury. Keep away from power lines or high energy sources at all times.



WARNING

Being struck by a moving marker can cause death or serious injury. Markers can move unexpectedly when SCV controls are operated. Keep marker switch OFF when not in use.

NOTICE

Control console face is backlit with a power switch on back side. Turn off console when not in use or tractor battery will drain.

Marker switch is an ON/OFF/ON type to select right or left hand marker operation. It is disabled when a planter fold function is selected. An indicator light illuminates when switch is ON.

Raise/wing lock and rotate/tongue switches are MOMENTARY ON/OFF/MOMEMENTARY ON type to select a planter fold function. They must be held in position while operating tractor SCV control for desired function to operate.

Down pressure switch is a MOMENTARY ON/OFF/ MOMENTARY ON type used to increase or decrease row unit down pressure.



Model 3660 control box

Work light switch is on ON/OFF type to control optional planter mounted work lights.

Point row switches are not used on Model 3660 planter. This function is controlled by Kinze Vision or Cobalt planter controller.

A 50 amp main control box fuse and 20 amp delayed air compressor fuse are located on control box front lower left face.

NOTE: Hydraulic weight transfer toolbar operates when planter is in motion and hydraulic seed rate drive is operating.

Model 3660 planters operate using three to five dual remote (SCV) hydraulic outlets:


- 1. Raise and lower planter during field operation with axle rockshaft (field lift).
- In conjuction with control console switches, controls row markers, center post, wing locks, rotation, and tongue extension.
- 3. Hydraulic seed rate drive.
- 4. Vacuum blower drive (optional).
- 5. Bulk fill blower drive (optional).

HYDRAULIC SEED RATE DRIVE

Refer to Ag Leader Integra or Kinze Cobalt operation manuals for information on setting and controlling hydraulic seed rate system.

HALL EFFECT SENSOR (Hydraulic Drive Only)

Set Hall effect sensor within 1/8" of pick-up disc.



Hall effect sensor

HYDRAULIC WEIGHT TRANSFER TOOLBAR

The hydraulic weight transfer system is standard. The hydraulic drive system powers the hydraulic weight transfer system. Pressure is set from the factory and does not require additional adjustment.

AG LEADER ELECTRIC CLUTCHES

Electric clutches along with GPS can stop seed flow by turning off seed meters (and planter sections) based on field mapping and previously planted areas.


TRANSPORT TO FIELD SEQUENCE

Position planter in a relatively flat open area. Avoid an area with furrows, etc.

SUMMARIZED TRANSPORT TO FIELD SEQUENCE

- 1. Remove and store tongue safety pin.
- 2. Remove and store transport latch locking pin.
- 3. Remove and store safety lockup.
- 4. Rotate planter to field position.
- 5. Lower planter on center post.
- 6. Raise planter using field lift.
- 7. Release wing locks.
- 8. Retract tongue.
- 9. Lower planter to ground.
- 10. Remove row marker lockups.

NOTE: Read following information for detailed instructions.



Tongue safety pin installed for transport



Tongue safety pin stored for field operation

1. With tongue fully extended, planter in transport position, and tractor shut down; remove tongue safety pin and place it in storage position.



Transport latch locking pin Locked transport position




Transport latch locking pin Storage position

2. Remove transport latch locking pin from locked position and place it in storage location.



Safety lockup in transport position



Safety lockup in storage position

- 3. Remove safety lockup from center lift cylinder and place in storage location on hose take-up.
- Start up tractor. Hold rotate/tongue switch to ROTATE and operate hydraulic control to rotate planter to field position. Transport latch will automatically release.

NOTE: Center post lift is used only for folding or unfolding planter. Raising and lowering planter during field operation is performed using field lift (axle rockshaft).

- Hold raise/wing lock switch to RAISE and operate hydraulic control to fully lower planter on center post.
- 6. Operate hydraulic control to raise planter using field lift.
- 7. Hold raise/wing lock switch to WING LOCK and operate hydraulic control to release wing locks.



Planter in field lift position



Wing lock release

- Operate hydraulic control to raise planter using field lift.
- 9. Hold rotate/tongue switch to TONGUE and operate hydraulic control to fully retract tongue. Tongue latch automatically engages.



Field lift/tongue retraction

10. Remove row marker lockups.

Model 3660



Row marker lockup

FIELD OPERATION



DANGER!

Contacting or coming close to power lines or other high energy sources will cause death or serious injury. Keep away from power lines or high energy sources at all times.

NOTICE

Raise planter out of ground when making sharp turns or backing up or equipment damage may result.

Raising and lowering planter is performed using field lift (axle rockshaft) during field operation.

NOTE: Field lift cylinders are rephasing cylinders and it is necessary to fully lower planter to rephase them. Cylinder stops can not be used.



Planting position

PLANTING SPEED

Planters are designed to operate in a speed range of 2 to 8 mph (3.2 - 12.9 kph). Higher ground speeds generally cause more variation in seed spacing. Speeds above 5.5 mph (8.8 kph) are typically not recommended.

FIELD TO TRANSPORT SEQUENCE

Position planter in a relatively flat area. Avoid areas with furrows, etc.

SUMMARIZED FIELD TO TRANSPORT SEQUENCE

- 1. Install row marker lockups.
- 2. Raise planter using field lift.
- 3. Extend tongue.
- 4. Engage wing locks.
- 5. Lower planter to ground.
- 6. Raise planter on center post.
- 7. Rotate planter to transport position.
- 8. Install safety lockup.
- 9. Install hitch safety pin.
- 10. Install transport latch locking pin.

NOTE: Read following information for detailed instructions.

1. Install row marker lockups.




Row marker lockup


- 2. Start tractor. Operate hydraulic control to raise planter using field lift.
- 3. Hold rotate/tongue switch to TONGUE and operate hydraulic control to fully extend tongue. Tongue latch automatically engages.



Field lift/tongue extension

- Hold raise/wing lock switch to WING LOCK and operate hydraulic control to engage wing locks.
- 5. Operate hydraulic control to lower planter using field lift.








Wing lock engaged



Transport position



Uncontrolled movement of equipment can cause loss of control and could result in death, serious injury, or damage to property and equipment. Install all safety pins before transporting equipment.



Tongue safety pin installed



Transport latch locking pin installed

- 8. Shut down tractor and remove safety lockup from storage location on hose take-up. Install safety lockup at center post as shown. Make sure top latch is around cylinder rod and fastened with safety pin, and that lower end is secured with detent pin.
- 9. Remove hitch safety pin from storage location and install in hitch.
- 10. Remove transport latch locking pin from storage location and install in transport latch.

VACUUM SYSTEM

Kinze vacuum seed metering system includes seed meters, seed discs, and an air system consisting of a hydraulic driven vacuum fan which draws air through manifolds, hoses, and seed meters on each row unit.



Moving fan blades can cause amputation or severe injury. Never operate vacuum fan with cover removed.

DIGITAL VACUUM READOUT

Digital vacuum readout is incorporated into in-cab display. Refer to the in-cab display operation manual for instructions.

VACUUM FAN MOTOR VALVE BLOCK ASSEMBLY

A pressure relief valve in the hydraulic circuit prevents build up of oil pressure over 35 PSI in case drain line when vacuum fan motor is operating. This valve will vent oil outside valve block through a drain hole in the aluminum valve block. This can occur whenever case drain is improperly connected or pressure in motor circuit builds.

See "Hydraulic Diagram - Vacuum Fan Motor System" in Lubrication and Maintenance section.


Valve block contains a check valve that prevents vacuum fan from operating in wrong direction if pressure is applied to return side of motor and allows fan to coast to a stop when tractor hydraulic control is returned to neutral position.

NOTE: Fan turns at a reduced speed If reverse pressure is applied.

ANALOG VACUUM OR PRESSURE GAUGE

Analog vacuum or pressure gauge connects directly to vacuum meter (vacuum) or bulk fill (pressure) manifold and is teed into digital sending units.

Only adjustment is to "zero" needle with no vacuum or pressure present. If there is a significant difference between gauge and a reading taken at meters, a different manifold location should be found to connect hose to gauge and digital sending unit.



NOTE: Analog gauges are identical EXCEPT for plug and hose barb locations in side of gauge housing. DO NOT connect vacuum meter or bulk fill hose to wrong gauge. Check plug and hose barb installation if readout is erratic or appears inaccurate.

BULK FILL SYSTEM



Seed flying out of disconnected delivery tube at high velocity can cause injury. Do not disconnect delivery tubes when system is operating.

NOTICE

Foreign materials can plug system. Make sure seed is clean and free of debris when filling bulk fill hoppers.

NOTICE

Do not turn on system with tractor engine at full speed or system damage may occur.

NOTICE

Do not operate bulk fill system above maximum system operating pressure of 20 inches of water or seed bridging may occur.

- Before filling hoppers refer to "Row Unit Operation" for additives information. Fill hoppers with seed, latch lids, and secure with pin.
- 2. Start bulk fill system with tractor engine at idle.
- 3. Increase engine speed to full and set initial system pressure using flow control valve.
- 4. Allow system to warm up and adjust pressure if necessary.




Bulk Fill Lid

Recommended pressures:

- Corn 12 inches of water
- Soybeans 10 inches of water
- Actual pressure needed is affected by seed size, shape, and coating.


BULK FILL ENTRAINER ACCESS


- 1. Shut down bulk fill system.
- 2. Loosen wing nut and turn retainer holding shutoff door in its storage location.
- Remove rubber plug closest to area in entrainer needing attention.
- 4. Insert shutoff door into open slot and push into entrainer at a slight upward angle.
- 5. When work is complete, remove shutoff door, return door to storage location, and plug open slot.



Bulk fill entrainer (end view)

BULK FILL TANKS - CLEAN OUT





Cleanout chute storage bracket

Cleanout chute installed

- Remove bulk fill tank cleanout chute from storage location beneath catwalk.
- 2. Position tube of chute under entrainer and attach hooks on each end of entrainment assembly.
- 3. Open cleanout doors and empty tank.
- 4. Close all cleanout doors and return cleanout chute to storage location.

BULK FILL SCALE PACKAGE OPTION

NOTICE

High-pressure water can damage display. Remove display before power washing planter.


NOTICE

Remove and store display at end of planting season. Damage from sun and weather exposure may result.

- Provides seed weight or estimated acres remaining for each bulk fill hopper.
- Displays total (gross) seed weight or estimated acres remaining for both hoppers combined.
- Warns operator when seed goes below a pre-defined level (when using a Kinze Vision display).

Operation of bulk fill Scale Package display is controlled by buttons located on its face:

- Two screen-defined selection buttons.
- Backlight ON/OFF button.
- UP/DOWN arrow buttons.
- Screen position is changed by loosening thumb screw on mount at back of monitor and repositioning screen.



SETUP BULK FILL SCALE PACKAGE DISPLAY

- 1. Press SET-UP button.
- First setup screen displays and ALARM LEVEL box is highlighted.
- 3. Press SELECT button.
- 4. Press UP or DOWN arrows to change alarm weight level. Select BACK to save changes.
- 5. Press UP or DOWN arrows to highlight WEIGHT/ACRE MODE box. Press SELECT button.
- Press UP or DOWN arrow buttons to toggle between weight or acre mode. This selection affects if values are displayed as pounds or estimated acres of seed remaining. Press BACK to save changes.
- 7. Press DOWN arrow to select second set-up screen.

NOTE: CALIBRATION# and SETUP# are automatic and do not need to be changed.

- 8. Select CONTRAST or BACKLIGHT. Use UP or DOWN arrow buttons to change levels. Press BACK to save changes.
- 9. Select BACK to return to main screen.

MONITOR SEED LEVELS

- 1. Main screen displays information for left and right hoppers.
- 2. Select either or R for individual hopper status information.
- Select BACK to return to main screen.
- 4. Press down arrow once or twice for GROSS screen to appear.
 - This provides combined status information for both hoppers.
- 5. Press down arrow again to return to main screen.









ENTER SEED INFORMATION

- 1. Highlight and select either L (left) or R (right) for the appropriate input screen.
- 2. At input screen, L or R side is indicated at left side of screen and seed weight or acres remaining is on right side.



3. Press arrow keys to select desired box; press SELECT to darken and use arrow keys to change.

NOTE: Seed information entered must be accurate for remaining estimated acres to calculate correctly.

- SEEDS/ACRE is population rate.
- SEEDS/LB value comes from seed specifications.
- ZERO is selected to zero hopper that is selected.
- 4. Select BACK to return to main screen.



AG LEADER INTEGRA DISPLAY

Integra is a full-featured hub of any precision farming operation. A large, full-color 12.1" HD touchscreen display is easy to read and offers powerful, year-round precision farming tools. Mapping, planter and application control, yield monitoring, real-time data logging, and more – are all controlled from the cab using the Integra display.

Four video camera inputs provide operators a better view of equipment operation and safety by allowing them to view live video on the display.

NOTE: See Integra operator manual for installation and programming.



Ag Leader Integra display

AG LEADER MONITORING CONTROL PACKAGE

The PMM Magnetic Distance Sensor Package includes a planter-mounted module enclosure with cover and mounting hardware, seed tubes w/sensors, planter harness, planter monitor cable, shaft rotation sensors and magnetic distance sensor components.

Ag Leader Integra display and associated cab harnesses are also required.




Planter Monitor Module (PMM)

AUXILIARY WORK LIGHTS PACKAGE

Auxiliary work lights package includes four LED lights with brackets and hardware to mount two lights on center lift cylinder and one on each wing. The provided wiring harness plugs into existing planter light harness.

Lights are controlled by the work light switch on control console.



Auxiliary work lights (Additional light mounted on opposite wing)

KINZE ISOBUS OPTION

Kinze ISOBUS option consists of a planter monitor module (PMM), and planter control module (PCM). Kinze planters will communicate directly with most ISO compatible monitors. See the Kinze ISOBUS manual for more information.

ROW MARKER OPERATION

A DANGER!

Contacting or coming close to power lines or other high energy sources will cause death or serious injury. Keep away from power lines or high energy sources at all times.





Model 3660

Marker switch

Row marker solenoid valves

Two solenoid valves on valve block at rear R.H. side of center frame, and a three position selector switch on control console permit operator to lower or raise desired row marker.

NOTICE

Marker position switch must be OFF when planter is not in use or tractor battery will drain.

See "Row Marker Speed Adjustment".

- 1. Select which row marker to lower on control console.
- 2. Operate hydraulic control to lower row marker.
- 3. Move control switch to other side to operate opposite row marker.
- 4. Raise row marker at end of field using hydraulic control.
- 5. After turn, using the hydraulic control, lower the pre-selected row marker.
- 6. Continue to follow this procedure.

NOTE: Both row markers can be lowered by operating switch in each position and hydraulic control twice. Row markers raise simultaneously with hydraulic control in raise position.

If electrical system does not operate properly:

- · Check fuse.
- Check wiring connections.
- Check control switch.
- Check solenoid, SOLENOID HOUSING IS MAGNETIZED WHEN ENERGIZED.

ROW MARKER SPEED ADJUSTMENT


NOTICE

Excessive row marker travel speed can damage row markers. Adjust flow controls before row markers are first used.

Marker hydraulic system includes two flow control valves. One flow control valve sets lowering speed and one sets raising speed of both markers. Flow controls determine amount of oil flow restriction through valves, varying marker travel speed.

Loosen jam nut and turn control clockwise, or IN to slow travel speed. Turn counterclockwise, or OUT to increase travel speed. Tighten jam nut after adjustments are complete.

NOTE: Tractors with flow control valves. Make row marker speed adjustment with tractor flow controls in maximum position. After row marker speed is set, adjust tractor flow controls to allow hydraulic control to stay in detent during marker raise or lower cycle.



Row marker speed control adjustment

NOTE: Hydraulics operate slowly when oil is cold. Make all adjustments with oil warm.

NOTE: On a tractor where oil flow cannot be controlled, tractor flow rate may be greater than rate marker cylinder can accept. Hold tractor hydraulic control lever until cylinder reaches end of its stroke. This occurs most often on tractors with an open center hydraulic system.


EVEN-ROW PUSH ROW UNIT

An Even-Row Push Row Unit Package is available to add one additional push row unit on outer L.H. side of front toolbar for use with Solid Row Interplant Package.

NOTE: See "Row Marker Adjustment" for determining correct length to set row marker assemblies when planting with even-row push row unit option.

An inner hitch with a $7\frac{1}{2}$ " offset mount is available from Kinze through your Kinze Dealer to plant two 15" rows between last year's 30" rows and avoid tire damage from stalks by driving off row

NOTE: install hitch onto 2-point hitch bar using R.H. hole If 2-Point Hitch Option is used. A 7½" offset mount is not needed. See "Offset Hitch Adjustment" for additional information.




ROW MARKER ADJUSTMENTS

1. Multiply number of rows by the average row spacing in inches to determine total planting width.

Row Marker Lengths		
12 Row 30"	360" (914.4 cm)	
16 Row 30"	480" (1219.2 cm)	

Model 3660

- 2. Lower planter and row marker assembly to ground.
- 3. Measure from planter center line to a point where blade contacts ground.
- 4. Adjust row marker extension so distance from marker disc blade to center line of planter is equal to total planting width. Adjust right and left row marker assemblies equally and securely tighten clamping bolts.



Row marker disc blade angle adjustment

NOTICE

Setting marker disc blade assembly at a sharper angle than needed adds stress to row marker assembly and shortens bearing and blade life. Set blade angle only as needed to leave a clear mark.


Marker disc blade is installed with concave side facing inward. Spindle assembly is slotted so hub and blade can be angled to throw more or less dirt.

- 5. Loosen hardware and move assembly as required.
- 6. Tighten bolts to specified torque.
- 7. Do a field test to ensure markers are properly adjusted.

NOTE: A notched marker blade is available from Kinze through your Kinze Dealer for use in more severe no till conditions.

ROW MARKER EVEN-ROW LENGTH ADJUSTMENT

Adjust marker extensions as shown below when using even-row push row unit option.



Center Of 15" Dimension
Planter To x 2 + Row = Between
Center Of Spacing Planter Center
Outer Row Line And
Unit Marker Blade

12 Row 30" With 12 Interplant Push Row Units (L.H. Marker 180" x 2 + 15" = 375") (R.H. Marker 165" x 2 + 15" = 345")

16 Row 30" With 16 Interplant Push Row Units (L.H. Marker 240" x 2 + 15" = 495") (R.H. Marker 225" x 2 + 15" = 465") NOTE: Readjust row markers when planting 30" rows.

Number Of Rows x Row Spacing (Inches)

=


Dimension Between Planter Center Line And Marker Blade

12 Rows x 30" Spacing = 360" Marker Dimension 16 Rows x 30" Spacing = 480" Marker Dimension


OFFSET HITCH ADJUSTMENT

An offset hitch is available from Kinze through your Kinze Dealer. Offset hitch provides centered and offset mounting positions for hitch clevis.

If tractor hitch is offset $7\frac{1}{2}$ " right of tractor center line, add $7\frac{1}{2}$ " to marker dimension on R.H. side of planter and subtract $7\frac{1}{2}$ " from marker dimension on L.H. side of planter.



POINT ROW CLUTCHES





Point row clutch

Electric-activated clutches disengage drive on either half of planter for finishing up fields or for long point row situations. Clutch selector switch is located on tractor control box.

NOTE: Liquid fertilizer piston pump has its own drive wheel and is not affected by point row clutch.

Clutch consists of a wrap spring riding on an input and output hub. Wrap spring is wrapped tightly over hubs during operation locking them together. Higher speeds create a tighter grip of spring on hubs.

Input end of spring is bent outward and is called the control tang. Control tang fits into a slot in stop collar located between input and output hubs over wrap spring. If stop collar is allowed to rotate with input hub, clutch is engaged. If stop collar is stopped from rotating, control tang connected to it is forced back and spring opens. This allows input hub to continue rotating without transmitting torque to output hub, stopping planter drive.

Stop collar is controlled by an electric solenoid and an actuator arm. When selector switch on tractor control box is OFF, solenoid coil is NOT ENERGIZED and actuator arm will not contact stop on stop collar, allowing it to rotate with hubs and drive planter.

When "DISENGAGED" solenoid coil IS ENERGIZED and plunger in solenoid coil pulls actuator arm against stop on stop collar, disengaging wrap spring and stopping planter drive.

AUXILIARY HYDRAULIC OPTION

A customer-supplied auxiliary hydraulic option may be added to provide 10 gpm of oil flow at rear of planter. It is designed for powering bulk seed handling equipment when planter is not in motion and is controlled by the same tractor hydraulic control as the seed rate hydraulic drive.



Pressurized hydraulic fluid can penetrate body tissue and result in death, serious infection, or other injuries. Fluid injected under skin must be IMMEDIATELY removed by a surgeon familiar with this type of injury. Make sure connections are tight and hoses and fittings are not damaged before applying system pressure. Leaks can be invisible. Keep away from suspected leaks. Relieve pressure before searching for leaks or performing any system maintenance.

NOTICE

Make sure MASTER switch is OFF on Kinze Vision or Cobalt display and planter is not in motion when using auxiliary hydraulic circuit.



Lower valve block

Customer-supplied hoses, fittings, and hydraulic outlets are added to ports AUX1 and AUX2 on lower valve block on back side of planter. Refer to "Hydraulic System Schematics" in the Lubrication and Maintenance section for additional information.

REAR TRAILER HITCH

Rear trailer hitch can tow a 3 or 4 wheel wagon behind planter. A spring, chain, and mounting bracket supports a 11/4" feed hose from hitch to piston pump. This extra length or loop is required to allow for planter to move into transport position without stretching hose.




Trailer hitch

NOTICE

Rear trailer hitch is designed for use with piston pump only. Maximum allowable hitch weight is 200 lb (90.71 kg). Do not exceed 6,000 lb (2,721.55 kg) gross towing weight or the equivalent of a loaded 500 gal (1,892.7 L) tank and running gear or equipment can be damaged.

NOTE: Periodically check feed hose for kinks to prevent restricted delivery rate.



FIELD TEST

Perform a field test with any change of field and/or planting conditions, seed size or planter adjustment to ensure proper seed placement and operation of row units.


- ☐ Check planter for front to rear and lateral level operation. See "Level Planter".
- ☐ Check **all** row units to be certain they are running level. Row unit parallel arms should be approximately parallel to the ground when planting.
- ☐ Check row markers for proper operation and adjustment. See "Row Marker Adjustment" and "Row Marker Speed Adjustment".
- ☐ Check for proper application rates and placement of granular chemicals on **all** rows. See "Field Check Granular Chemical Application".
- ☐ Check for desired depth placement and seed population on all rows. See "Field Check Seed Population".
- ☐ Check for proper application rates of fertilizer on **all** rows. See "Fertilizer Application Rate Chart".

Reinspect machine after field testing.

- Hoses And Fittings
- Bolts And Nuts
- Cotter Pins And Spring Pins
- ☐ Drive Chain Alignment


FIELD CHECK SEED POPULATION

1. Tie up one or more sets of closing wheels by running a chain or rubber tarp strap between the hopper support panel and closing wheels. It may be necessary to decrease closing wheel arm spring tension.



Planting depth adjustment handle

2. Plant a short distance and check to see if seed is visible in the seed trench. Adjust planting depth to a shallower setting if seed is not visible and recheck.



Planting depth adjustment

3. Measure ½1000 of an acre. See chart for correct distance for row width being planted. For example, if planting 30" rows ½1000 of an acre would be 17' 5".

1/1000 Acre Seed Population Count Row Width/Distance						
Row Width	15"	18"	19"	30"	36"	38"
Distance	34'10"	29'0"	27'8"	17'5"	14'6"	13'10"

NOTE: Seeds may bounce or roll when planting with closing wheels raised and planting depth set shallow affecting seed spacing accuracy.

- 4. Count seeds in measured distance.
- 5. Multiply number of seeds placed in 1/1000 of an acre by 1000. This gives total population.

EXAMPLE: 30" row spacing 17' 5" equals 1/1000 acre.

26 seeds counted x 1000 = 26,000 seeds per acre

Seed count can be affected by drive wheel and seed meter drive ratio, tire pressure, and/or seed meter malfunction.

- 1. If seed check shows average distance between seeds in inches is significantly different than seed rate chart indicates, first check drive ratio between drive wheel and seed meter. Check drive wheel air pressure, check for incorrect sprocket(s) in driveline and check drive and driven sprockets on transmission(s) for proper selection.
- 2. Check for seed meter malfunction. For example, if spacing between kernels of corn at the transmission setting being used is 8" and a gap of 16" is observed, a finger has lost its seed and not functioned properly. If two seeds are found within a short distance of each other, finger has metered two seeds instead of one.
- 3. See "Seed Meter (Finger Pickup) Troubleshooting" or "Seed Meter (Brush-Type) Troubleshooting" in Troubleshooting Section of this manual.

DETERMINING POUNDS PER ACRE (BRUSH-TYPE METER)

Seeds per acre ÷ Seeds per pound (from label) = Pounds per acre

If seeds per pound information is not available use the following averages:

- 2,600 seeds per pound for medium size soybeans
- 15,000 seeds per pound for medium size milo/grain sorghum
- 4,500 seeds per pound for medium size cotton

DETERMINING BUSHELS PER ACRE

Pounds per acre ÷ Seed unit weight = Bushels per acre

Average Unit Weight of:

- 1 Bushel Soybeans = 60 Pounds
- 1 Bushel Milo/Grain Sorghum = 56 Pounds
- 1 Bushel Cotton = 32 Pounds

If seed population check shows planting rate is significantly different than seed rate chart shows or if a particular meter is not planting accurately, see "Brush-Type Seed Meter Maintenance" and "Seed Meter (Brush-Type) Troubleshooting".


FIELD CHECK GRANULAR CHEMICAL APPLICATION

Temperature, humidity, speed, ground conditions, flowability of different material, or meter obstructions can affect granular chemical rate of delivery.



Agricultural chemicals can cause death or serious injury to persons, animals, and plants or seriously damage soil, equipment, or property. Read and follow all chemical and equipment manufacturers labels and instructions.

Perform a field check to determine application rates.



Granular chemical field check

- 1. Fill insecticide and/or herbicide hoppers.
- 2. Attach a calibrated vial to each granular chemical meter.

NOTE: Disengage clutch to avoid dropping seed during test.

- 3. Lower planter and drive 1320 feet at planting speed.
- 4. Weigh chemical in ounces caught in one vial.
- 5. Multiply that amount by factor shown to determine pounds per acre.

Pounds Per Acre		
Row Width	Factor	
30"	.83	
36"	.69	
38"	.65	

EXAMPLE: You are planting 30" rows. You have planted for 1320 feet at desired planting speed. You caught 12.0 ounces of chemical in one vial. 12.0 ounces times 0.83 equals 9.96 pounds per acre.

NOTE: Check calibration of all rows.

METERING GATE

Use metering gate setting as a starting point for distributing insecticide or herbicide. Charts are based on 5 mph (8 kph) planting speed. Use a higher gate setting for speeds faster than 5 mph (8 kph) and a lower setting for speeds slower than 5 mph (8 kph).

PLANTING DEPTH


Planting depth is maintained by adjustable row unit gauge wheels. Depth adjustment range is approximately ½" to 3½".


- 1. Raise planter to remove weight from wheels.
- 2. Push down on depth adjustment handle and reposition it forward to decrease or rearward to increase planting depth. Initially adjust all units to the same setting.
- Lower planter and check operation and planting depth of all row units. Readjust individual rows as needed for uniform operation.




Planting depth adjustment

"V" CLOSING WHEEL ADJUSTMENT (RUBBER OR CAST IRON)








"V" closing wheels should have enough down pressure to close the seed trench and ensure good soil to seed contact. Move 5-position quick adjustable down force lever on the top of closing wheel arm to the rear to increase closing wheel spring pressure. Move lever forward to decrease pressure. Adjust all row units to a similar setting. Light soil usually requires less down force at average depth (approximately 2") while heavy soil requires increased down force.

Eccentric bushings in the wheel arm stop allow for lateral adjustment of the "V" closing wheel assembly. Use a ¾" wrench to loosen hardware attaching closing wheel arm to wheel arm stop. Use another ¾" wrench to turn eccentric bushings until **closing wheels are aligned with seed trench**. Tighten hardware.

Closing wheels can be installed "offset" (to improve residue flow) or "directly" opposite. Use forward installation holes If set "directly" opposite.

CLOSING WHEEL SHIELD (RUBBER OR CAST IRON "V" CLOSING WHEELS)

Optional closing wheel shield is installed on underside of closing wheel arm to help prevent root balls and stalks from clogging closing wheels.




Closing wheel shield (Closing wheel removed)

DRAG CLOSING ATTACHMENT

Drag closing attachment pulls loose soil over seed trench.


NOTE: Use of a seed firming wheel or other seed firming device is recommended with drag closing attachment.

Front and rear adjustment is made using slotted holes in blades. Adjust all rows the same. Wheel arm stop eccentric bushings provide lateral adjustment. Use a ¾" wrench to loosen closing wheel arm to wheel arm stop hardware. Use another ¾" wrench to turn eccentric bushings until drag closing attachment is aligned with seed trench. Tighten hardware.




Drag closing attachment


COVERING DISCS/SINGLE PRESS WHEEL ADJUSTMENT



Press wheel down force adjustment

Check operation of covering discs/single press wheels after adjusting planting depth. Initial press wheel down force spring setting is 2½" between mounting arm tab and locking nut. Loosen ½" locking nut and turn adjusting bolt in to increase down force or out to decrease down force. Tighten locking nut against spring plug. Adjust all row units to a similar setting.





Covering disc adjustments

Eccentric bushings in the wheel arm stop allow for lateral adjustment of covering discs/single press wheel assembly. Use a ¾" wrench to loosen hardware attaching closing wheel arm to wheel arm stop. Use another ¾" wrench to turn eccentric bushings until covering discs/single press wheel assembly is aligned with seed trench. Tighten hardware. Two sets of holes in mounting arm locate covering discs for staggered or side-by-side operation. Five sets of holes in each disc bracket allow ½" incremental blade depth adjustment. Slotted holes in disc mount and bracket allow for 0° - 15° blade angle adjustment. Adjust covering discs on all row units to similar settings.

SEED HOPPERS

Mechanical seed hopper has a capacity of 1.9 bushels.

Vacuum seed hopper has a capacity of 1.75 bushels.

Use clean seed and make certain there are no foreign objects inside when filling seed hopper. Replace hopper lids after hoppers are filled to prevent accumulation of dust or dirt in seed meter which can cause premature wear. See "Finger Pickup Seed Meter" and/or "Brush-Type Seed Meter".

Periodically empty hoppers completely to remove any foreign objects and to ensure proper seed meter operation.



Mechanical seed hopper

Disengage meter drive and hopper latch and lift hopper off hopper support. See "Seed Meter Drive Release".

SEED METER DRIVE RELEASE

A clutch release mechanism disengages seed meter drive from seed meter to remove seed hopper or prevent meter from operatiing. Releasing drive allows operator to check granular chemical application rates without dropping seed. It also allows one or more rows to be disconnected when finishing fields.


Turn knob ¼ turn counterclockwise to release or ¼ turn clockwise to engage drive.



Seed meter drive release

ROW UNIT EXTENSION BRACKETS

Row unit extension brackets extend row units rearward 4" to provide clearance for coulter mounted residue wheels and HD single disc fertilizer openers.




Row unit extension brackets

ROW UNIT CHAIN ROUTING

Row unit drive chains must be properly tensioned and aligned for proper operation and to minimize wear.


Inspect and replace weak, worn or broken springs, idlers, and idler bushings.




Mechanical pull row unit meter drive



Mechanical push row unit meter drive




Row unit granular chemical drive




Vacuum pull row unit meter drive



Vacuum push row unit meter drive




NOTE: Install connector link with closed end facing direction of travel.




NOTE: Reverse idler when worn on one side for extended use.


QUICK ADJUSTABLE DOWN FORCE SPRINGS OPTION (STANDARD OR HEAVY DUTY)


Standard and heavy duty quick adjustable down force springs are available in increase penetration in hard soil and keep row unit from bouncing in rough field conditions. Two springs per row, one on each side parallel arms, are used unless equipped with row unit mounted no till coulters. Row unit mounted no till coulters require four springs per row.




Four springs per row (Quad)









Position 1 (Least)

Position 2

Position 3

Position 4 (Most)

There are four positions to set down pressure spring tension.

	Standard and Heavy Duty Spring Down Force Pressure*					
	2 Sp	rings	4 Sp	rings		
Position	Standard D8249	Heavy Duty D21337	Standard D8249	Heavy Duty D21337		
1	41lb (18.6 kg)	43 lb (19.5 kg)	74 lb (33.6 kg)	80 lb (36.3 kg)		
2	73 lb (33.1 kg)	86 lb (39.0 kg)	120 lb (54.4 kg)	144 lb (65.3 kg)		
3	136 lb (61.7 kg)	167 lb (75.7 kg)	255 lb (115.7 kg)	307 lb (139.3 kg)		
4	207 lb (93.9 kg)	249 lb (113.0 kg)	369 lb (167.4 kg)	470 lb (213.2 kg)		
*Pressure does not include weight of row unit, seed, or options.						

NOTICE

Springs must be installed with open side of spring hooks toward seed hoppers to prevent binding on spring mount adjustment pins.

- 1. Raise planter and remove spring mount pin at top of spring.
- Slide mount to desired position and install pin.


NOTE: Adjust springs for field conditions. Too much down pressure in hard field conditions can cause row units to lift planter and keep drive wheels from making contact. Too much down pressure in soft field conditions can cause row unit to run too deep.

PNEUMATIC DOWN PRESSURE PACKAGE OPTION


Row unit down pressure can be adjusted on-the-go as field conditions change with pneumatic down pressure option. A cab-mounted control box adjusts pressure (Older models may have a digital readout). A planter-mounted 12 VDC air compressor with 3 gallon capacity air tank supplies air for the down pressure system.

Packages include upper and lower air spring mounting castings for pull row units (front and rear air spring mounting castings for push row units), 150 psi rated air springs, %" O.D. nylon hoses, dual solenoid air valve and stainless steel, 160 psi, 2" liquid-filled gauge and planter wiring harness.

Pneumatic down pressure row unit extension brackets are required in some applications.




Pull row unit air spring




Push row unit air spring

NOTE: Assist springs are available through your Kinze dealer if additional down pressure is needed. One spring is installed on outer side of parallel arms on each side of row unit as shown below.



Pull row unit assist springs




Push row unit assist springs

FIELD OPERATION

NOTE: Adjust down pressure with planter lowered and row openers in ground for most accurate adjustment. Pressure can be adjusted from tractor using control console, or at planter using manual control valves on compressor assembly.







Air compressor assembly controls

ADJUST DOWN PRESSURE FROM CAB

Push toggle switch left to increase or right to decrease pressure.

ADJUST DOWN PRESSURE AT PLANTER

Push and hold decrease or increase button on compressor assembly to decrease or increase pressure.

NOTE: Value on the air pressure gauge is NOT down pressure force. Multiply air pressure (psi) by four (4) to calculate down pressure.

LOCK UP PUSH ROW UNITS EQUIPPED WITH PNEUMATIC DOWN PRESSURE SPRINGS

- 1. Disconnect electric power supply to compressor.
- 2. Press and hold button on solenoid until pressure gauge reads zero.
- 3. Lock up units. See "Interplant Push Unit Lockup" for instructions.
- 4. Turn shutoff valve handle perpendicular to valve body to turn off air supply to push row units.

NOTE: If control console is ON and pneumatic down force is not set to zero, compressor will start when electric power supply is reconnected.

5. Reconnect electric power supply to compressor.

INTERPLANT PUSH ROW UNIT CLUTCH SPROCKET


Push row unit clutch sprocket disengages interplant drive from push row unit drill shaft when only pull row units are used.

DISENGAGE

Rotate knurled collar ¼ turn. Rock drill shaft slightly using a ¾" wrench to take pressure off of spring loaded pins in clutch to allow pins to "pop" out, disengaging drive.

ENGAGE

Rotate knurled collar ½ turn and turn drill shaft with a ½" wrench until drive pins engage drive sprocket.



Interplant clutch sprocket


INTERPLANT PUSH ROW UNIT VACUUM HOSE SHUTOFF





Interplant vacuum hose shutoff

When push row units are not used, move row unit end of 2" vacuum hose on each push row unit to storage mount located on side of shank except for center push row unit as shown below at right.




Center push row vacuum hose storage mount

INTERPLANT PUSH ROW UNIT LOCKUPS


Push row unit lockups lock interplant row units in a raised position.



Improper lifting of row units can cause serious injury. An empty row unit requires minimum 90 lb (40.8 kg) lift. Set down pressure springs to minimum, lower planter to ground, and empty seed hopper before attempting to lift with this lever.




Lift lever positioned on push row unit



Lockup released for field operation




Lift lever in storage location



Push row unit locked in raised position

To lock in raised position:

- 1. Set row unit down pressure springs to minimum setting.
- 2. Lower the planter to the planting position.
- 3. Empty seed hoppers.
- 4. On each push row unit lockup, flip the spring tab forward.



- 5. Using the lift lever, raise the push row unit to allow the spring loaded lockups to snap into locked position under the row unit stops.
- 6. Repeat Steps 4 and 5 on remaining push row units.


To release lockups:

- 1. Lower the planter to the planting position.
- 2. On each push row unit lockup, flip the spring tab rearward.

- 3. Using the lift lever, raise the push row unit to allow the spring loaded lockups to snap out of locked position. Lower row unit to the ground.
- 4. Repeat Step 3 on remaining push row units.



Lift lever in storage location



GENERAL PLANTING RATE INFORMATION

NOTICE

Seed additives added in the hopper may affect finger pickup seed meter performance and accelerate wear.

NOTE: Seed size and shape may affect planting rate.

NOTE: Speeds above 5.5 MPH (8.8 KPH) can adversely affect seed spacing.

Finger Pickup Corn Meter

Larger grades generally plant more accurately at the high end of the ground speed range than smaller grades. Higher than optimum speeds may result in population rate increase or higher incidence of doubles, particularly with small seed. Medium round corn seed is most desirable for planting accuracy at optimum speed.

Finger Pickup Oil Sunflower Meter

Larger grades generally plant more accurately at the high end of the ground speed range than smaller grades. Higher than optimum speeds may result in population rate increase or higher incidence of doubles, particularly with small seed. No. 3 and/or No. 4 size oil sunflower seeds are recommended for use in finger pickup seed meters equipped with oil sunflower fingers. No. 1 and/or No. 2 size confectionery sunflower seeds are recommended for use in finger pickup seed meters equipped with corn fingers.

Brush-Type Seed Meter (Soybean, Milo/Grain Sorghum, Acid-Delinted Cotton)

Rate charts are given in seeds per acre as well as seed spacing in inches rounded to nearest tenth of an inch. Because of large range in seed size, pounds per acre is not a suggested method of selecting transmission settings. Smaller size seed pounds per acre may be below what was expected and large seed pounds per acre may appear above expectations. To determine pounds per acre, use formula given in "Determining Pounds Per Acre (Brush-Type Seed Meter)" in "Check Seed Population" in Machine Operation section of this manual.

BRUSH-TYPE SEED METER

	Crop	Disc Color-Code (Disc Part No.)	Upper Brush Retainer	Cells	Seed Size Range	*Lubricant
	Soybean	Black (GA5794)	GD11122	60	2200 to 4000 seeds/lb.	Graphite Talc
	Specialty Soybean	Dark Blue (GA6184)	GD11122	48	1400 to 2200 seeds/lb.	Graphite Talc
RA	Small Milo/Grain Sorghum	Red (GA5982)	GD8237	30	14,000 to 20,000 seeds/lb.	Talc
RR	Large Milo Grain Sorghum	Light Blue (GA6187)	GD8237	30	10,000 to 16,000 seeds/lb.	Talc
M RAIL RAIL DD	High-Rate Small Milo/Grain Sorghum	Red (GA5795)	GD8237	60	12,000 to 18,000 seeds/lb.	Talc
RALLA	High-Rate Large Milo/Grain Sorghum	Yellow (GA6633)	GD8237	60	10,000 to 14,000 seeds/lb.	Talc
	Cotton, Acid-Delinted	White (GA5796)	GD11122	30	4200 to 5200 seeds/lb.	Talc
自	Large Cotton, Acid Delinted	Tan (GA6168)	GD11122	36	3800 to 4400 seeds/lb.	Talc
昌	High-Rate Cotton, Acid-Delinted	Light Green (GA6478)	GD11122	48	4200 to 5200 seeds/lb.	Talc
P	Hill-Drop Cotton, Acid-Delinted	Brown (GA6182)	GD11122	12 (3 to 6 seeds/ cell)	4000 to 5200 seeds/lb.	Talc
P	Small Hill-Drop Cotton, Acid- Delinted	Dark Green (GA7255)	GD11122	12 (3 to 6 seeds/ cell)	5000 to 6200 seeds/lb.	Talc

*For More information on application rate see Additives section.



Use GD11122 upper brush retainer when using cotton and soybean discs.



Use GD8237 upper brush retainer when using milo/grain sorghum discs.

Turn seed disc counterclockwise when installing on meter hub while tightening two wing nuts that retain disc. Seed disc should have slight resistance when rotated counterclockwise after wing nuts are tight.

Brush-type seed meter attaches to seed hopper same as finger pickup seed meter. Secure to bottom of seed hopper with two 5/16" thumbscrews. Tighten thumbscrews slightly with pliers. DO NOT OVER TIGHTEN.

Misalignment between drive coupler and seed meter input shaft may cause erratic seed spacing from momentary stoppage of seed disc. Check alignment and adjust as needed.

Refer to planting rate charts in this manual for recommended seed drive transmission sprocket combinations.



Shown without seed disc installed

NOTICE

Replace hopper lids after hoppers are filled to prevent accumulation of dust or dirt in seed meter which will cause premature wear.

NOTE: Clean seed is required to ensure accurate seed metering from brush-type seed meters. Remove seed discs daily and check seed meter or brushes for buildup of foreign material, such as hulls, stems, etc.

FINGER PICKUP SEED METER



Сгор	Fingers	*Lubricant
Corn	Part No.: GR1848 - Finger Assembly, Corn	Graphite Talc
No. 1 and/or No. 2 size Confectionery Sunflower Seeds	Part No.: GR1848 - Finger Assembly, Corn	Talc
No. 3 and/or No. 4 size Oil Sunflower Seeds	Part No.: GR2154 - Finger Assembly, Oil	Talc
Blank fingers replace alternate fingers to reduce planting rate by half while allowing the finger wheel to maintain a minimum of 40 RPM when planting low rates.	Part No.: GD11787 - Half Rate Blank Finger	Graphite Talc

*For More information on application rate see Additives section.

NOTE: Always field check seed population to verify planting rates.

NOTE: Refer to planting rate charts in this manual for recommended seed drive transmission sprocket combinations.

VACUUM SETTINGS

	J J III J _ I								
	Crop	**Seed Disc Kit	Seed Disc Part No.	Ejector Wheel (Color)	Cells	Seed Size Range	Singulator Zone Setting	Vacuum Setting Inches of Water (kPa)	Lubricant
	Corn	G9040X	B0678 (Light Blue)	1 row 5 punches (Light Blue)	40	35-70 lbs/80k (2500-5000 seeds/kg)	2	18-20 (4.5-5.0)	Graphite* Talc* Bayer Fluency† (if mandated)
	Soybean	G9041X	B0848 (Black)	2 rows 6 punches (Black)	120	2200-4000 seeds/lb (4850-8820 seeds/kg)	0	10-14 (2.5-3.5)	Graphite* Talc* Bayer Fluency [†] (if mandated)
Salining	Sugar Beet	G9043X	B0683 (Dark Orange)	1 row 6 punches (Dark Orange)	60	Pelletized	2	15 (3.75)	Graphite* Bayer Fluency† (if mandated)
Sall Market	Milo	G9043X	B0683 (Dark Orange)	1 row 6 punches (Dark Orange)	60	10,000-20,000 seeds/lb (22000-44000 seeds/kg)	2	15 (3.75)	Graphite* Talc* Bayer Fluency† (if mandated)
	Sunflower	G9042X	B0684 (Gray)	1 row 5 punches (Gray)	40	Oil seeds #2, 3, 4	2	12-18 (3.0-4.5)	Graphite* Talc* Bayer Fluency† (if mandated)
	Sunflower	G9042X	B0684 (Gray)	1 row 5 punches (Gray)	40	Oil seeds #5	2	5-8 (1.25-2.0)	Graphite* Talc* Bayer Fluency† (if mandated)
Shining	Specialty Disc 1	G9272X	B0912 (Green)	1 row 6 punches (Green)	60	Cotton	2	15-20 (3.75-5.0)	Graphite* Talc as needed* Bayer Fluency† (if mandated)
William Control	Specialty Disc 2	G9273X	B0914 (Brown)	1 row 6 punches (Green)	60	Black turtle & navy edible beans	2	15-20 (3.75-5.0)	Graphite* Talc as needed* Bayer Fluency† (if mandated)
	Specialty Disc 3	G9308X	B0913 (Dark Blue)	1 row 6 punches (Green)	60	Pinto & Great Northern edible beans & low-rate soybean	2	15-20 (3.75-5.0)	Graphite* Talc as needed* Bayer Fluency† (if mandated)

Install selected seed disc. Position vacuum cover on meter by aligning keyhole slots over bolt heads. Push cover on meter and turn counter clockwise to lock in place.

^{*}For More information on application rate, see Additives section.

^{**}Includes seed disc, ejector wheel, and spring.

[†]Bayer Fluency Agent is only required to be used in place of graphite or talc lubricants on vacuum equipped planters that are sowing neonicotinoid treated seeds in Canada. Refer to the Bayer Fluency Agent section for more information.


NOTE: See <u>"Field Check Seed Population" on page 2-30</u> for more information. Always field check seed population to ensure planting rates are correct.


NOTE: Singulator settings are marked from 0 - 3.

NOTE: Mixing seed sizes and shapes affects meter performance. Use consistent seed size and shape.

NOTE: Use 1 tablespoon powdered graphite with each standard hopper fill of seed. Seed treatment, foreign material, dirt or seed chaff may cause gradual reduction of seed disc fill (population). See "Additives" pages for more information.

NOTE: Excessive seed treatment, humidity, and light-weight seed can affect meter performance. Use ½ cup of talc with each standard hopper fill of seed and mix thoroughly to coat all seeds and adjust rates as needed. Use of talc aids seed flow into meter, singulation, and disc seed drop.






NOTE: Foreign material in seed disc orifices, such as seed chips, hulls, stems, etc., may affect seed delivery. Clean seed ensures accurate seed metering from vacuum seed meter. Remove Seed discs daily to check for buildup of foreign material in seed disc orifices.

Air inlet screens allow air to enter system and aids in keeping field residue or other foreign material out of meter.

See "Vacuum Seed Meter Maintenance" on page 5-19 and "Preparation for Storage" on page 5-37 in Lubrication and Maintenance section for more information.



NOTE: Damaged seed or seed containing foreign material will cause plugging of seed disc orifices and require more frequent seed meter cleanout to prevent underplanting.

Wheel-Type Ejectors


Wheel-type ejectors expel seed remants from seed disc orifices. These ejectors are disc specific and colored coded to match disc.

NOTICE

Replace hopper or tank lids after filling to prevent accumulation of dust or dirt in seed meter resulting in premature wear.

NOTE: Seed size, seed shape, seed treatments, travel speed, and planting rate affect meter performance.

1. Select seed disc and ejector to match crop and population.



Singulator Adjustment Wheel

- 2. Adjust singulator wheel to initial setting. Seed size, seed shape, seed treatments, travel speed and planting rate all affect meter performance.
- 3. With vacuum fan running, lower planter to planting position and drive forward a short distance to load seed into seed disc cells.
- 4. Adjust vacuum level to initial setting according to tables on page.

NOTE: Vacuum reading will be much lower when seed disc cells are empty. Load all seed cells before setting vacuum level.

NOTE: Operate vacuum fan 3-5 minutes to bring oil up to normal operating temperature prior to making final vacuum level adjustment.

4. Adjust vacuum level to initial setting according to tables on page.

NOTE: Vacuum reading will be much lower when seed disc cells are empty. Load all seed cells before setting vacuum level.

NOTE: Operate vacuum fan 3-5 minutes to bring oil up to normal operating temperature prior to making final vacuum level adjustment.

SEED METER CLEANOUT

NOTE: Use of damaged seed or seed containing foreign material will cause plugging of seed cell orifices and require more frequent seed meter cleanout to prevent underplanting.

Thorough seed meter cleanout is important to maintain genetic purity.

- 1. Disengage seed drive and remove seed hopper and meter.
- 2. Dump seed from right rear corner of hopper into a container.
- 3. Lay hopper on its right side. Push release button and rotate seed meter vacuum cover clockwise to align keyhole slots with bolt heads. Lift off cover.
- 4. Rotate seed disc hub clockwise to unlock and remove seed disc.
- 5. Empty meter.
- 6. Thoroughly inspect meter to ensure all seed is removed.
- 7. Replace seed disc. Install vacuum cover.

ADDITIVES

The use of graphite is recommended to promote seed flow, provide lubrication for the seed meter and to help dissipate static charge buildup. Among the available dry seed lubricants graphite is the most effective and easiest to use and it requires no mechanical agitation

CONVENTIONAL HOPPERS

Mix one tablespoon of **powdered graphite** with seed each time hoppers are filled. Regular graphite use prolongs life of the seed meter components, improves seed spacing, and may reduce buildup of seed treatments.

Lubricant Application Rate			
Graphite			
Conventional Hoppers	1 Tbs./Hopper Fill		
Bulk fill Hoppers 1 Pound Bottle/Hopper			
Ta	Talc		
Conventional Hoppers	1/4 C.*		
Bulk fill Hoppers 4 Pounds/Hopper*			
*Double amount of talc for sunflowers.			

NOTE: DO NOT apply graphite only in center of hopper. It will filter too quickly through the seed and not distribute as evenly as desired.

Apply graphite around outer perimeter of hopper.

BULK FILL HOPPERS

Mix 1 pound bottle of powdered graphite each time the bulk seed hopper is filled. Graphite should be added in layers as the bulk seed hoppers are filled. Regular graphite use prolongs life of the seed meter components, improves seed spacing, and may reduce buildup of seed treatments.



Adding graphite to conventional hopper



Adding graphite bulk fill hopper

NOTE: Additional graphite may be required to retard buildup of seed treatments on meter components. More frequent cleaning of monitor seed tubes may be necessary due to use of additional graphite.

Talc seed lubricant may be used as a drying agent in addition to graphite lubrication. The drying agent may improve seed release and/or to retard buildup of seed treatments on meter components.

- 1. Fill hopper ½ full of seed, add ¼ cup (conventional); 2 pounds (bulk fill) of talc and mix thoroughly.
- 2. Finish filling hopper, add another 1/4 cup (conventional); 2 pounds (bulk fill) of talc and mix thoroughly.
- 3. Adjust rate of talc use as needed so all seeds are coated, while avoiding a buildup of talc in bottom of hopper.

Humid conditions and/or small sized seeds with extra seed treatment may require additional talc to maintain meter performance.

NOTE: Liquid seed treatments or innoculants may create buildup on the seed disc or brushes. Check frequently for proper population and/or seed delivery when using any liquid seed treatment.


Completely mix all treatments with seed following manufacturers' recommendations. Seed treatment dumped on top of seed after hopper is filled may not mix properly and cause seed bridging, reducing population or stopping meter from planting.

FRAME MOUNTED COULTER (PULL ROW)

Frame mounted coulters with 1" bubbled, 1" fluted (8 flutes) or $\frac{3}{4}$ " fluted (13 flutes) blades are used on pull row units only.

Springs provide down pressure on coulter for maximum penetration while exerting less shock load on row unit.

Initial coulter blade location is in top hole. Relocate blade to one of lower two holes (1" increments) as wear occurs or for deeper blade operation.



Frame mounted coulter adjustment

DOWN PRESSURE ADJUSTMENT

NOTICE

Excessive down pressure can damage coulter components when coulter strikes an obstacle. Do not set down pressure higher than needed for consistent soil penetration.

Raise planter. Turn spring adjustment bolts clockwise to increase or counterclockwise to decrease down pressure. Set both springs to specification shown in following table:

Frame Mounted Coulter Spring Downpressure Settings				
End flush with spring anchor bar	Extended ½" through spring anchor bar	All threads used		
275 lb (124.7 kg)	400 lb (181.4 kg)	500 lb (226.8 kg)		

RESIDUE WHEELS (FRAME MOUNTED COULTER)

NOTICE

Tined wheel forward mounting positions cannot be used on four rows behind axle due to inadequate clearance.


Residue wheels attach to frame mounted coulter with two cap screws and sleeves allowing the unit to free-float. A 2-position spindle bolt mounting positions wheels interlocked or staggered. Depth adjustment is made with a spring-loaded cam and pin with 11 positions in 1/4" increments. A high point on the cam allows wheels to be locked up.


A weed guard on the inboard side of each wheel helps prevent weed wrap which can cause premature bearing failure.

NOTE: Opening in weed guard must face down.

ROW UNIT MOUNTED DISC FURROWER (PULL ROW)

Disc furrowers are used to clear crop residue, dirt clods, and dry soil from in front of row units for a clean and smooth seed bed. The disc furrower may be equipped with 12" solid blades or 12" notched blades. Notched blades are for heavier residue conditions and cut crop residue and move it aside to prevent plugging or pushing.





Disc furrower adjustment

Vertical adjustment can be made in $\frac{1}{3}$ " increments. Remove lynch pin in vertical support arm and move arm up or down. Reinstall lynch pin. Finer adjustment can be made by removing lynch pin and using $\frac{5}{3}$ " x $2\frac{1}{4}$ " set screw to clamp support arm in position. Slotted holes in support arm allow front to rear disc blade adjustment. Blades can be adjusted so front edges meet or cutting edge of one blade overlaps edge of other blade.


NOTE: Dust cap must be removed to make adjustments.

ROW UNIT MOUNTED BED LEVELER (PULL ROW)

NOTE: Row unit mounted bed leveler is not compatible with row spacings less than 36".

Vertical adjustment can be made in $\frac{1}{3}$ " increments. Remove lynch pin in vertical support arm and move arm up or down. Reinstall lynch pin. Finer adjustment can be made by removing lynch pin and using $\frac{5}{8}$ " x $2\frac{1}{4}$ " set screw to clamp support arm in position.

Slotted holes in support arm allow blade adjustment. Blades can be tilted up or down.



Bed leveler adjustment

BAYER FLUENCY AGENT


Bayer Fluency Agent is an alternate seed lubricant by Bayer Crop Science. The intent of this product is to replace graphite and talc lubricants and to lower the amount of dust emissions from planter vacuum fans.

This product, as tested by Kinze, is compatible with Kinze's bulk fill system and vacuum meters. Due to limited testing, wear life characteristics of meters and bulk fill systems that use Bayer Fluency Agent are not yet known. Please follow Bayer Fluency Agent instructions for rates and mixing directions.

NOTE: Presently, Bayer Fluency Agent is only required to be used in Canada with Bulk Fill or Vacuum planters that plant corn or beans treated with neonicotinoids. Farms outside of Canada, farms not using seed treated with neonicotinoids, and farms not using pneutmatic metering devices do not need to use Bayer Fluency Agent. All planters not equipped with vacuums or fans are exempt from using Bayer Fluency Agent.


ROW UNIT MOUNTED RESIDUE WHEEL

Row unit mounted residue wheels are used on pull and push row units.





Row Unit Mounted Residue Wheel


Two adjustable springs on each residue wheel parallel links provide down force adjustment. Position 1 provides minimum down pressure and position 3 maximum down pressure.




Raise row unit and reposition springs to adjust down pressure.







Wheel angle adjustment



Wheel lock up

A full threaded bolt and jam nut located on the upper link sets maximum depth for loose soil conditions. Initial setting is 1¾" above row unit double disc opener depth.


Three holes in upper link adjust wheel angle. With wheel mount in most vertical position, using the rear hole in the upper link, the residue wheel is most aggressive. Moving wheel mount to a forward hole reduces aggressiveness of residue wheel for use in mulch till applications where soil is loose.

To lock residue wheel up, remove ½" x 5" lockup bolt, raise residue wheel and install bolt.

SPIKED CLOSING WHEEL

Spiked closing wheels crumble the sidewall, allowing roots to pentrate soil. They can be used on pull row units and push row units.

Align spiked closing wheels straight across from each other, in most rearward holes on closing wheel arm. Set the wheels 1" - $1\frac{1}{4}$ " (2.5 - 3.1 cm) apart at the closest point. If large amounts of contouring is being done, mount wheels in the forward most hole. This will reduce drifting of row unit.




Row Unit Spiked Closing Wheel

ROW UNIT MOUNTED NO TILL COULTER

Row unit mounted no till coulters with 1" bubbled, 1" fluted (8 flutes) or ¾" fluted (13 flutes) blades may be used on pull row units and push row units (¾" fluted shown). Four quick adjustable down force springs are required per row when using row unit mounted no till coulters. See "Quick Adjustable Down Force Springs Options".

Align coulter blade to row unit double disc openers. Adjust by loosening four attaching bolts, moving coulter arm, and tightening four attaching bolts. Coulter blade can be adjusted to one of four $\frac{1}{2}$ " incremental settings in the forked arm. Initial location is the top hole.



Row Unit Mounted No Till Coulter


Move blade as it wears to one of the three lower hole to maintain coulter blade at or slightly above opener discs as required. Adjust coulter below depth of double disc opener blades in very hard soil conditions such as compacted wheel tracks to improve opener penetration and cutting of surface residue.

Check operating depth by setting planter down on a level concrete floor and checking relationship between coulter blade and row unit opener blade. Make sure planter is level and coulter is square with planter frame and aligned with row unit disc opener.

NOTE: Torque %" spindle hardware to 120 ft-lb (162.7 N-m).

COULTER MOUNTED RESIDUE WHEELS

Coulter mounted residue wheels are designed for use on pull row units and push row units. Row unit extension brackets are required on the four center pull row units if the planter is equipped with coulter mounted residue wheels.



NOTE: Opening in weed guard must face down.



Coulter mounted residue wheels

Residue wheels attach to row unit mounted coulter with two cap screws and sleeves allowing unit to free-float. A 2-position spindle bolt mounting positions wheels interlocked or staggered. Depth adjustment is made with a spring-loaded cam and pin with 11 positions in ½" increments. A high point on the cam allows wheels to be locked up.

A weed guard on the inboard side of each wheel helps prevent weed wrap which can cause premature bearing failure.

GRANULAR CHEMICAL HOPPER AND DRIVE



Agricultural chemicals can cause death or serious injury to persons, animals, and plants or seriously damage soil, equipment, or property. Read and follow all chemical and equipment manufacturers labels and instructions.

The granular chemical hopper has a 1.4 cubic feet capacity.

Make sure no foreign objects get into hopper when it is being filled. Replace hopper lids after filling to prevent accumulation of dirt and moisture.

A metering gate on bottom of hopper regulates the application rate. See "Dry Insecticide and Dry Herbicide Application Rate Charts" in this manual. Calibrate using chemical manufacturers' instructions.




Granular chemical hopper

Granular chemical clutch drive coupler and meter shaft can be disengaged and engaged by turning throwout knob at rear of hopper support panel.

Rotate knob $\frac{1}{4}$ turn counterclockwise to disengage and $\frac{1}{4}$ turn clockwise to engage.

Slotted holes in hopper support panel and clutch housing allow for alignment adjustment between clutch drive coupler and meter shaft.




Granular chemical drive release

SPRING TOOTH INCORPORATOR

Spring tooth incorporator smooths soil behind row unit and incorporates granular chemicals.

Adjust two mounting chains on each spring tooth incorporator so there is approximately 1/8" slack in chain when unit is lowered to planting position.

NOTE: Spring tooth incorporator is not compatible with covering discs/single press wheel option.





Spring tooth incorporator


GRANULAR CHEMICAL BANDING OPTIONS

Granular chemical banding options allow 41/2" slope-compensating banding, straight drop in-furrow placement or 14" rear banding.

NOTE: Granular chemical rear bander is not compatible with covering discs/single press wheel option.








14" rear banding

41/2" slope-compensating bander Straight drop in-furrow placement

GRANULAR CHEMICAL BANDER SHIELD



Optional granular chemical bander shield is installed on underside of wheel arm stop to shield crop residue from lodging in granular chemical bander.

DRY INSECTICIDE APPLICATION RATES APPROXIMATE POUNDS/ACRE AT 5 MPH


CLAY GRANULES		APPROXIMATE POUNDS/ACRE AT 5 WIFT
10 11 12 13 6.9 14 7.7 15 8.5 16 9.6 17 10.7 18 11.4 19 10.7 18 19 13.1 20 14.2 21 15.5 22 16.4 23 17.2 24 18.8 25 29 26 26 23.0 27 24.1 28 29 27 24.1 28 29 30 SAND GRANULES 5 6 4.9 7 5.3 8 6 6 7 7 5.3 8 9 7 8 9 7 8 10 8 9 7 8 11 10 10.2 11 11 10.2 11 11 10.2 11 11 11 10.2 11 11 11 10.2 11 11 11 10.2 11 11 11 11 10.2 11 11 11 11 11 11 11 11 11 11 11 11 11	Meter Setting	30" Rows
11		
12		
13 6.9 14 7.7 15 8.5 16 9.6 17 10.7 18 11.4 19 13.1 20 14.2 21 15.5 22 16.4 23 17.2 24 18.8 25 20.9 26 23.0 27 24.1 28 29 27.8 30 29.6 SAND GRANULES 5 4.9 7 5.3 8 9 7.8 9 7.8 10 8.9 11 10.2 12 11.2 13 12.6 14 14 14.1 15 15.5 16 17.5 17 19.4 18 19.2 24.3 20 25.7 21 27.6 21 29.6	11	
13 6.9 14 7.7 15 8.5 16 9.6 17 10.7 18 11.4 19 13.1 20 14.2 21 15.5 22 16.4 23 17.2 24 18.8 25 20.9 26 23.0 27 24.1 28 29 27.8 29 27.8 30 29.6 SAND GRANULES 5 4.9 7 5.3 8 6.3 9 7.8 10 8.9 11 10.2 12 11.2 13 12.6 14 14 1.1 15 15.5 16 17.5 17 19.4 18 19.2 24.3 20 25.7 21 27.6 29.6	12	6.1
14	13	
15		
16		
17		
18		
19		
20 14.2 15.5 16.4 17.2 22 18.8 25 29.9 24.1 28.8 29.9 29.6 29.6 29.6 29.6 10.2 11.2 13.3 12.6 14.1 15.5 16.5 17.5 17.5 17.5 17.5 17.5 17.5 17.5 17		
21		
16.4 17.2 24 24 25 26 20.9 26 27 24.1 28 29 27.8 29 30 29.6 SAND GRANULES 5 6 7 6 6 7 8 8 9 7 8 10 10 8.9 11 11 11 10.2 12 13 14 14 15 15 17 18 19 19 19.4 18 19 20 20 22 28 21 28 22 29.6		
17.2 24 24 28 25 26 27 24.1 28 29 27.8 30 29.6 SAND GRANULES 5 6 4.9 7 8 8 9 7.8 10 11 10 10.2 12 11 11.2 13 14 14 15 15 16 17 19 19 19 19 19 19 19 19 19 19 19 19 19		
24		
25 20.9 26 23.0 27 24.1 28 25.4 29 27.8 30 29.6 SAND GRANULES 5 2.9 6 4.9 7 5.3 8 6.3 9 7.8 10 8.9 11 10.2 12 11.2 13 12.6 14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6	23	17.2
25 20.9 26 23.0 27 24.1 28 25.4 29 27.8 30 29.6 SAND GRANULES 5 2.9 6 4.9 7 5.3 8 6.3 9 7.8 10 8.9 11 10.2 12 11.2 13 12.6 14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6	24	18.8
26 27 24.1 28 25.4 29 29.6 29.6 29.6 29.6 29.6 29.6 29.6 2	25	
27		
28 29 27.8 27.8 29.6 SAND GRANULES 5 4.9 6 4.9 7 5.3 8 6.3 9 7.8 10 8.9 11 10.2 12 11.2 13 12.6 14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6		
29 27.8 29.6 SAND GRANULES 5 2.9 6 4.9 7 5.3 8 6.3 9 7.8 10 8.9 11 10.2 12 11.2 13 12.6 14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 22 25.6		
39.6 SAND GRANULES 5 2.9 6 4.9 7 5.3 8 6.3 9 7.8 10 8.9 11 10.2 12 11.2 13 12.6 14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6		
SAND GRANULES 5 2.9 6 4.9 7 5.3 8 6.3 9 7.8 10 8.9 11 10.2 12 11.2 13 12.6 14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6		
5 2.9 6 4.9 7 5.3 8 6.3 9 7.8 10 8.9 11 10.2 12 11.2 13 12.6 14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6	30	
6 4.9 7 5.3 8 6.3 9 7.8 10 8.9 11 10.2 12 11.2 13 12.6 14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6		
7 5.3 8 6.3 9 7.8 10 8.9 11 10.2 12 11.2 13 12.6 14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6		
8 6.3 9 7.8 10 8.9 11 10.2 12 11.2 13 12.6 14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6	6	
9 7.8 10 8.9 11 10.2 12 11.2 13 12.6 14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6		
10 8.9 11 10.2 12 11.2 13 12.6 14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6		
11 10.2 12 11.2 13 12.6 14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6		
12 11.2 13 12.6 14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6		
13 14 14 15 15 15 16 17 19.4 18 19 24.3 20 25.7 21 22 27.6 22	11	10.2
13 14 14 15 15 15 16 17 19 19 18 19 24.3 20 25.7 21 22 29.6	12	11.2
14 14.1 15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6	13	12.6
15 15.5 16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6		
16 17.5 17 19.4 18 21.8 19 24.3 20 25.7 21 27.6 22 29.6		
17 18 21.8 19 24.3 20 25.7 21 22 29.6		
18 21.8 19 24.3 20 25.7 21 27.6 22 29.6		
19 24.3 20 25.7 21 27.6 22 29.6		21.8
20 25.7 21 27.6 22 29.6	10	24.0
21 22 29.6	19	24.3
22 29.6		
22 23.0		2/.6
22 0	22	29.6
	23	32.0
24 34.4	24	34.4
25 36.9	25	36.9

NOTE: Chart represents average values and should be used only as a starting point. Granular chemical flows through meter opening at a nearly uniform rate regardless of roller speed. Your actual rate will vary depending on insecticide, planting speed, and plant population. Planting speed/ground speed has the greatest effect on application rate.

Field check your actual rate with insecticide you are using at speed and population you will be planting. See "Checking Granular Chemical Application Rate" in Machine Operation section for more information.



DOUBLE DISC FERTILIZER OPENER



Double disc fertilizer opener

Position double disc fertilizer openers to place fertilizer no closer than 2" to either side of row. Fertilizer depth is approximately 4" If planter frame is level and at proper 20" operating height. Soil conditions can affect depth slightly.

NOTE: Do not set opener depth with spring pressure. Opener is designed to operate against a depth stop and spring up when encountering a foreign object or hard ground.

Down pressure spring is factory preset at 250 lb (113.4 kg) but can be adjusted for various soil conditions.

- 1. Loosen jam nut with a 15/16" wrench.
- 2. Use a 1" wrench to turn adjustment bolt clockwise to increase tension or counterclockwise to decrease tension.
- Tighten jam nut.

NOTICE

Do not operate double disc openers at full down pressure tension on rocky ground or disc blades will chip.


Maintain a gap of ½2" to ½6" between opener blades at the closest point. Blade adjustment is made by moving inside spacer washers to outer side of blade. Check bearing assembly rivets are not contacting shank after making adjustment.

Outer scrapers on each disc blade can be adjusted for wear. Make sure scrapers are adjusted to allow only slight blade contact.

Opener assembly is designed to be locked in a raised position when fertilizer attachment is not in use or during storage.

- 1. Raise planter and place blocks under openers.
- 2. Lower planter until pivot section hole aligns with mounting bracket hole.
- 3. Remove lockup pin from mounting bracket storage position and install through lockup hole.
- 4. Secure with cotter pins.

NOTCHED SINGLE DISC OPENER



Notched single disc opener adjustments



Compressed spring may fly out of this assembly if attempting to disassemble and cause injury. Do not take apart this assembly.

Disc blades are sharp and can cut causing serious injury. Wear gloves when working on or turning disc blades by hand.

NOTICE

Never strike knife with heavy object. Damage to knife will occur.

If knife to disc blade clearance is too large, soil or residue can wedge between knife and blade, and blade will not turn.

1. <u>Adjust knife to disc blade</u> contact. Loosen or tighten %" lock nuts to adjust knife's entire leading edge against disc blade. Turn blade and check for slight resistance without freewheeling. Readjust knife to blade's tight spot as needed.

NOTICE

Adjust liquid drop tube out of path of soil flow across knife. Drop tube and tab wear quickly if not correctly adjusted.

2. Adjust scraper and drop tube. Loosen two 5/16" hex head cap screws. Adjust scraper until just touching disc blade. Adjust drop tube until it is centered between knife and disc blade. Tighten screws. Turn blade and check for slight resistance without freewheeling. Repeat as needed. Insert flat bladed pry bar or screwdriver between knife and drop tube above drop tube tab. Carefully bend tube until 1/4"-3/8" from disc blade.

NOTE: Maximum disc blade depth 4" (10.2 cm).

3. Adjust blade depth. Loosen three ½" hex head cap screws and jam nuts in opener mount. Adjust opener assembly up or down to desired blade depth. Tighten center hex head cap screw and jam nut first to set proper disc blade angle. Tighten remaining hex head cap screws and jam nuts. Torque hex head cap screws and jam nuts to 57 ft-lb (77.29 N-m). Check fertilizer hose clearance and adjust as necessary.

RESIDUE WHEEL ATTACHMENT FOR NOTCHED SINGLE DISC FERTILIZER OPENER



Notched single disc opener residue wheel attachment

Residue wheel attachment for notched single disc fertilizer opener is used where row unit mounted residue wheel attachments cannot be installed. Residue wheel is attached to notched single disc fertilizer opener with $\frac{5}{8}$ " x $\frac{7}{2}$ " and $\frac{1}{2}$ " x $\frac{6}{2}$ " hardware.

Maximum depth is set by lifting residue wheel and moving adjustment lever down to increase depth or up to decrease depth in 1" increments (in relation to blade depth setting). Adjust all rows the same. Residue wheel down force is maintained by a torsion spring and is not adjustable.

DEPTH/GAUGE WHEEL ATTACHMENT FOR NOTCHED SINGLE DISC FERTILIZER OPENER



Notched single disc opener depth/gauge wheel


Depth/gauge wheel attachment for notched single disc fertilizer opener is used where additional gauging is required to maintain desired fertilizer opener depth. Depth/gauge wheel is attached to notched single disc fertilizer opener using a mounting block fastened to the pivot arm with 5/8" hardware through disc blade bearing.

Depth adjustment is made using 3 adjustment holes in depth/ gauge wheel mounting block. Moving depth/gauge wheel increases/decreases depth in approximate 1" increments in relation to blade depth setting made at vertical mounting post.



HD SINGLE DISC FERTILIZER OPENER





HD single disc opener

R.H. configuration shown (Overhead view)

Recommended placement of fertilizer with HD single disc fertilizer opener is 31/2" - 4" from row.

NOTICE

Never place fertilizer closer than 2" to row or seeds may be damaged.

Maximum blade depth is approximately 5" with planter frame level and at 20" operating height. Soil conditions can affect depth slightly.

Raise planter to remove weight from fertilizer opener. Loosen inside adjustment nut with 1½" wrench. Turn outside nut clockwise to decrease or counterclockwise to increase blade depth. One full turn of blade depth adjustment nut changes blade depth 3½". Tighten inside nut tight against block. Adjust all fertilizer openers to same depth.

Fertilizer opener down pressure can be adjusted from 250 lb (113.4 kg) to 640 lb (290.3 kg).

NOTICE

Do not operate HD single disc fertilizer openers at full down pressure tension on rocky ground or disc blades will chip.

NOTE: DO NOT adjust spring preset dimension less than $9\frac{1}{2}$ ".


NOTE: Excessive down pressure can cause planter frame up-lift and affect machine performance. Planter frame should be 20" from ground in planting position. Excessive down pressure in loose soil conditions can cause openers to run too deep and push dirt ahead of opener and may stop soil press wheel and opener blade from turning.

Raise planter to remove weight from fertilizer opener. Turn spring preset nut clockwise to increase and counterclockwise to decrease down pressure. Adjust all rows to a similar setting. Minimal spring pressure for acceptable operation is recommended. See chart for spring length settings.


Adjust spring loaded dry fertilizer drop tube/scraper periodically to maintain 1/8" gap between drop tube and opener blade. If this dimension is not maintained fertilizer may not drop in proper location.

Loosen scraper adjustment bolt. Slotted hole in scraper allows up or down adjustment.

Spring Preset				
Length	Down Pressure			
11" (27.9 cm)	250 lb (113.4 kg)			
10¾" (27.3 cm)	320 lb (145.1 kg)			
*10½" (26.7 cm)	370 lb (167.8 kg)			
101/4" (26 cm)	450 lb (204.1 kg)			
10" (25.4 cm)	520 lb (235.8 kg)			
9¾" (24.8 cm)	580 lb (263.1 kg)			
9½" (24.1 cm)	640 lb (290.3 kg)			
*Initial setting				



Adjust liquid drop tube/scraper so there is slight contact between blade and scraper lower leading edge, and ½" clearance between liquid drop tube trailing edge and blade. Blade should turn with minimum amount of drag.



NOTE: Soil press wheel is not for gauging fertilizer opener operating depth.

Additional press wheel down pressure may be desirable in heavy moist soils. Turn press wheel spring adjustment bolt clockwise to increase down pressure.




Press wheel down pressure adjustment

HD single disc fertilizer opener can be raised and locked up when fertilizer attachment is not used or during storage.

NOTE: A lockup bar automatically raises and locks soil press wheel when blade assembly is raised.

- 1. Place planter in planting position.
- 2. Remove outside blade depth adjustment.
- 3. Raise planter until adjustment bolt clears adjustment block.
- 4. Raise spring to clear blade assembly and raise blade assembly until storage strap can be positioned on lockup pin. Install hair pin clip.
- 5. Reinstall depth adjustment nut and tighten



HD opener lockup

LIQUID FERTILIZER ATTACHMENT



WARNING

Agricultural chemicals can cause death or serious injury to persons, animals, and plants or seriously damage soil, equipment, or property. Read and follow all chemical and equipment manufacturers labels and instructions.



CAUTION

Prior to 2012 production. Overfilling tank can cause siphoning, tank collapse, personal injury, and damage to property and equipment. Do not overfill tank. Do not leave planter unattended when filling tank. Close fill valve and open tank lid if siphoning occurs. Follow all chemical manufacturers first aid, cleanup, and handling instructions.

NOTICE

Placing fertilizer too close to seeds or in excessive amounts can cause germination or seedling damage. Check with your fertilizer dealer or manufacturer for correct amount and placement.



3660 conventional w/vacuum

CHECK VALVES






Old style non-repairable check valve


New style repairable check valve

Optional low rate check valves are available for in-line installation between liquid fertilizer squeeze or piston pump and openers to ensure equal distribution of product at low rates. Check valves eliminate anti-siphon loops.

PISTON PUMP

NOTE: Keep manuals shipped with pump and flow divider with this manual.





Piston pump

Adjusting delivery rate

NOTE: Delivery rate chart at back of this section provides approximate application rate only. Delivery varies with temperature and fertilizer.


Loosen %" lock nut that secures arm with pointer and rotate scale flange with adjustment wrench until pointer is over desired scale setting. Tighten %" lock nut. DO NOT OVERTIGHTEN.

NOTE: Periodically check flow to all rows. Set rate is still delivered to remaining rows if one or more lines are plugged.

PISTON PUMP GROUND DRIVE WHEEL SPRING ADJUSTMENT

Initial down pressure spring tension on piston pump ground drive wheel,is set leaving $12^{1/4}$ " between the bottom of mounting plate and plug on top of spring. This dimension is taken with planter raised (tire not contacting the ground). Further adjustment can be made to fit conditions.


NOTE: Piston pump ground drive wheel assembly can be locked in raised position when not in use. Remove two cap screws that attach upper end of spring to spring mount. Reattach spring using upper holes in spring mount. Reverse procedure to reset for field use.



CLEANING

Clean tanks, hoses, and metering pump thoroughly with water at end of planting season or prior to an extended period of non-use. Do not allow fertilizer to crystallize from cold temperature or evaporation.

On machines equipped with piston pump, take apart and clean strainer located between piston pump and ball valve daily. Remove the end cap to clean the screen. See Piston Pump Storage in Maintenance Section of this manual.



LIQUID FERTILIZER PISTON PUMP APPLICATION RATES GALLONS PER ACRE

Model NGP-6055 Piston Pump With 18 Tooth Sprocket (Planter Equipped With One Piston Pump)

Pump Setting	2	3	4	5	6	7	8	9	10
12 Row 30"	10.4	15.5	20.6	25.8	31.0	36.2	41.3	46.5	51.7
16 Row 30"	6.9	10.3	13.7	17.1	20.6	24.0	27.5	30.9	34.3

Chart is for planters equipped with contact drive. Check tires for correct operating pressure.

Chart calculated based on a solution weighing ten pounds per gallon.

NOTE: Fertilizer application rates can vary from weights calculated in above chart. Make field checks to be sure you are applying fertilizer at desired rate.

NOTE: Periodically check flow rates to all rows. Set flow rate is still delivered to remaining rows even if a lines are plugged.

To check the exact number of gallons your fertilizer attachment will actually deliver on a 30" row spacing:

- 1. Remove hose from one fertilizer opener and insert it into a collection container secured planter frame.
- 2. Engage fertilizer attachment and drive forward for 174'.
- 3. Measure fluid ounces caught in container and multiply by 100. Divide that amount by 128. Result is gallons of fertilizer delivered per acre when planting in 30" rows.
- 4. Rinse collection container and repeat test on other rows if necessary.

LUBRICATION

Following pages show locations of all lubrication points. Proper lubrication of moving parts helps ensure efficient operation of your Kinze planter and prolongs the life of friction producing parts.

LUBRICATION SYMBOLS





Lubricate at frequency indicated with SAE multipurpose grease.






Lubricate at frequency indicated with high quality SAE 10 weight oil or spray lubricant.

SEALED BEARINGS

Sealed bearings are used on your Kinze planter to provide trouble free operation.

These are located on drive shafts, row units, and transmission bearings. Sealed bearings are lubricated for life and are not serviceable.



Sealed bearing (Typical)

WHEEL BEARINGS


All drive, transport, and marker hub wheel bearings should be repacked annually and checked for wear.

- 1. Raise wheel off ground.
- 2. Check for bearing endplay by moving wheel side to side.
- 3. Rotate wheel to check for bearing roughness. If bearings sound rough, remove hub and inspect bearings.


NOTE: To repack wheel hubs, follow procedure outlined for wheel bearing replacement in this section except bearings and bearing cups are reused.

DRIVE CHAINS


Lubricate all transmission and drive chains daily with a high quality chain lubricant. Extreme operating conditions such as dirt, temperature, or speed may require more frequent lubrication. If a chain becomes stiff, it should be removed, soaked, and washed in solvent to loosen and remove dirt from joints. Soak chain in oil so lubricant can penetrate between rollers and bushings.




Pull row unit drive chains




Row Unit Electric Clutches




Row unit granular chemical drive chains



Push row unit drive chains



Liquid fertilizer ground drive chains (Piston pump)




Liquid fertilizer ground drive chains (Piston pump)


BUSHINGS

Lubricate bushings at frequency indicated.


Check each bolt for proper torque. If bolt is loose, removed it and inspect bushing for cracks and wear. Replace bushing if necessary. Use only hardened flat washers. Replace damaged flat washers with proper part. Torque hardware to 130 ft-lb (176.2 N-m).




Pull/push row unit parallel linkages (8 per row)




Bed leveler parallel linkages (6 per row)




Row unit mounted disc furrower parallel linkages (6 per row)





Interplant push row unit lockups - 2 per row



Row unit "v" closing wheel, covering discs/ single press wheel and/or drag closing wheel eccentric bushings (2 per row)







Transport latch (1 location)

CENTER POST


NOTICE

Any oil or grease on center post and poly wear pads will attract dirt and accelerate wear. Do not lubricate center post and poly wear pads.

Center post is clad with stainless steel. Keep stainless steel surface clean and free of any lubrication to prolong service life. See "Wear Pad Adjustment/Replacement" for more information.

U-JOINT SLIDES

Lubricate all U-joint slides daily with a high quality lubricant.




U-joint slide

LIQUID FERTILIZER PISTON PUMP CRANKCASE OIL LEVEL

Check crankcase oil daily and maintain at oil level check plug. Fill as needed with EP 90 weight gear oil. Total oil capacity is approximately ¾ pint.

Refer to operator and instruction manual supplied with pump and flow divider for more information.



Piston pump oil fill and check plug locations

PTO PUMP SHAFT COUPLING (TRACTOR DRIVEN PTO PUMP AND OIL COOLER OPTION)

NOTE: Clean and grease PTO shaft coupling each time pump is installed.

NOTE: Apply coating of high-speed industrial coupling grease, such as Chevron Coupling Grease meeting AGMA CG-1 and CG-2 Standards, to extend shaft spline life.

Chevron® trademark is owned by Chevron Products Company. AGMA is the acronym for the American Gear Manufacturers Association.




1%"-21 spline PTO pump shown


PLANTER MOUNTED PTO PUMP DRIVELINE

NOTICE

Lubricate every 8 hours or equipment failure can occur.



Planter mounted PTO shaft -Lubricate every 8 hours




- * Lubricate ball, socket and inner cross kit with at least 15 pumps of grease.
- ** Lubricate outer cross kit and all other areas with at least 5 pumps of grease.


NOTE: Visually inspect all wear surfaces inside double yoke to insure presence of grease after lubricating.

GREASE FITTINGS


Parts equipped with grease fittings should be lubricated at frequency indicated with an SAE multipurpose grease. Clean fitting thoroughly before using grease gun. Frequency of lubrication recommended is based on normal operating conditions. Severe or unusual conditions may require more frequent attention.

NOTE: Numbers on illustration below correspond to photos on following pages showing lubrication frequencies.







1. Row marker assemblies
3 fittings per assembly - 2 assemblies




2. Wing hinges 4 fittings per hinge - 2 hinges




3. Wing wheel pivot 4 fittings per wing wheel - 4 wing wheels




4. Wing lift cylinders
1 per cylinder - 4 cylinders




5. Rock shaft 2 fittings




6. Field stabilizer1 fitting per stabilizer - 2 stabilizers




7. Tongue hook 2 fittings




8. U-joints 2 fittings per U-joint - 2 U-joints w/out Interplant 4 U-joints w/Interplant




9. Row marker breakaway 1 fitting per breakaway - 2 breakaways




Transport wheel bearings
1 fitting per wheel - 4 wheels




10. Rotate cylinder 2 fittings




Notched single disc fertilizer opener - 1




Liquid fertilizer piston pump - 4 NOTE: Fill on outboard stuffing box until lubricant seeps out of drain hole in bottom.



Frame Mounted Coulter - 1 Per Arm



Double disc fertilizer opener - 1




HD Single Disc Fertilizer Opener - 2 (Located On Wheel Arm And Opener Mount)



HD single disc fertilizer opener - 1 (Located on disc opener spindle hub)



Gauge Wheel Arms - 1 Per Arm (Seals in gauge wheel arm are installed with lip facing out to allow grease to purge dirt away from seal. Pump grease into arm until fresh grease appears between washers and arm.)



Residue wheel attachment for use with notched single disc fertilizer opener - 1

MOUNTING BOLTS AND HARDWARE

Before operating planter for the first time, check all hardware is tight. Check all hardware again after first 50 hours of operation and beginning of each planting season.

All hardware used on the Kinze planter is Grade 5 (high strength) unless otherwise noted. Grade 5 cap screws are marked with three radial lines on the head. Hardware must be replaced with equal size, strength, and thread type.



WARNING

Loose transport wheel lug nuts can result in wheel separation from planter and can result in death, serious injury, and damage to property and equipment. Check transport wheel lug nut torque before operating planter for the first time and periodically thereafter.

NOTICE

Over-tightening hardware can reduce its shock load capacity and cause equipment failure.



GRADE 2No Marks



GRADE 5 3 Marks



GRADE 8 6 Marks

TORQUE VALUES CHART - PLATED HARDWARE

	Grade 2		Gra	<u>de 5</u>	Grade 8		
Diameter	Coarse	Fine	Coarse	Fine	Coarse	Fine	
1/4"	50 in-lb	56 in-lb	76 in-lb	87 in-lb	9 ft-lb	10 ft-lb	
5/16"	8 ft-lb	9 ft-lb	13 ft-lb	14 ft-lb	18 ft-lb	20 ft-lb	
3/8"	15 ft-lb	17 ft-lb	23 ft-lb	26 ft-lb	33 ft-lb	37 ft-lb	
7/16"	25 ft-lb	27 ft-lb	37 ft-lb	41 ft-lb	52 ft-lb	58 ft-lb	
1/2"	35 ft-lb	40 ft-lb	57 ft-lb	64 ft-lb	80 ft-lb	90 ft-lb	
9/16"	50 ft-lb	60 ft-lb	80 ft-lb	90 ft-lb	115 ft-lb	130 ft-lb	
5⁄8"	70 ft-lb	80 ft-lb	110 ft-lb	125 ft-lb	160 ft-lb	180 ft-lb	
3/4"	130 ft-lb	145 ft-lb	200 ft-lb	220 ft-lb	280 ft-lb	315 ft-lb	
7⁄8"	125 ft-lb	140 ft-lb	320 ft-lb	350 ft-lb	450 ft-lb	500 ft-lb	
1"	190 ft-lb	205 ft-lb	480 ft-lb	530 ft-lb	675 ft-lb	750 ft-lb	
11⁄8"	265 ft-lb	300 ft-lb	600 ft-lb	670 ft-lb	960 ft-lb	1075 ft-lb	
11⁄4"	375 ft-lb	415 ft-lb	840 ft-lb	930 ft-lb	1360 ft-lb	1500 ft-lb	
1%"	490 ft-lb	560 ft-lb	1100 ft-lb	1250 ft-lb	1780 ft-lb	2030 ft-lb	
1½"	650 ft-lb	730 ft-lb	1450 ft-lb	1650 ft-lb	2307 ft-lb	2670 ft-lb	

NOTE: Torque unplated hardware and bolts with lock nuts approximately $\frac{1}{3}$ higher than above values. Torque bolts lubricated prior to installation to 70% of value shown in chart.

CYLINDER ROD PISTON RETAINING NUT TORQUE CHART

	Non-Nylock Nut	Nylock Nut			
½"-20	55-70 ft-lb	45-55 ft-lb			
	(75-95 N-m)	(61-75 N-m)			
³⁄4"-16	115-125 ft-lb	100-115 ft-lb			
	(156-169 N-m)	(136-156 N-m)			
7/8"-14	150-180 ft-lb	130-150 ft-lb			
	(203-244 N-m)	(176-203 N-m)			
1"-14	275-330 ft-lb	250-275 ft-lb			
	(373-447 N-m)	(339-373 ft-lb)			
11/8"-12	300-375 ft-lb	275-300 ft-lb			
	(407-508 N-m)	(373-407 N-m)			
1¼"-12	300-375 ft-lb	275-300 ft-lb			
1/4-12	(407-508 N-m)	(373-407 N-m)			

TORQUE VALUES - PNEUMATIC DOWN PRESSURE

TOTAGE WILDED		LO I MEDIDATIO DOMINI MEDIDAME
	Diameter	Torque Value
	1/8" NPT	120 in-lb Maximum
	1/2"-13	180 in-lb Maximum
	3⁄4"-16	180 in-lb Maximum

NOTE: Use these torque values with pneumatic down pressure components.

SPECIAL TORQUE VALUES

OI EGIAL TORQUE VALUES					
Row unit parallel linkage bushing	130 ft-lb				
hardware	(176 Nm)				
%" No till coulter spindle	120 ft-lb				
hardware	(162 Nm)				
Center section transport tire lug	180 ft-lb				
nuts	(244 Nm)				
Wing ground drive tire lug belte	90 ft-lb				
Wing ground drive tire lug bolts	(122 Nm)				

TIRE PRESSURE



Explosive separation of rim and tire parts could result in death or serious injury Rim and tire servicing, improper use of rims and tires, or worn or improperly maintained tires could result in a tire explosion.

To prevent tire explosions:

- Maintain proper tire pressure. Inflating a tire above or below the recommended pressure can cause tire damage.
- Mount tires only by properly trained personnel using proper equipment.
- Replace tires with cuts or bubbles. Replace damaged rims. Replace missing lug bolts and nuts.
- Do not weld or heat wheel assembly. Heating increases tire pressure.

TRANSPORT TIRES




Over-inflation of tires can result in explosive separation of rim and tire and cause death or serious injury. Different size rims are designed for different tire pressures. Inflate to correct pressure for specific rim size.

INFLATION SPECIFICATIONS

Transport (center section) 41x11 70R 22.5 75 psi (517.1 kPa) recommended/90 psi (620.5 kPa) max.


Ground drive (wings) 7.50" x 20".....40 psi (275.7 kPa)

Liquid fertilizer piston pump 7.60" x 15" 40 psi (275.7 kPa)



Tire locations

PLANTER MOUNTED PUMP DRIVE AND OIL COOLER OPTION



Vacuum fan assembly




Bulk fill fan assembly

Flow control valve - Bulk fill fan (opposite side)
Flow control valve - Vacuum fan (shown)

NOTICE

Clean and grease PTO shaft coupling with high-pressure industrial coupling grease (Chevron coupling grease or equivalent) meeting AGMA CG-1 and CG-2 Standards each time driveshaft is installed or premature wear and equipment failure can occur.

Chevron® trademark is owned by Chevron Products Company. AGMA is the acronym for American Gear Manufacturers Association.



PTO pumps and reservoir assembly

Drain reservoir and change filter annually.

- 1. Remove the left side panel from pump housing and pull drain hose out to clear planter.
- 2. Remove cap from end of drain hose and drain oil into container.
- 3. Replace 10-micron spin-on filter.
- 4. Replace and tighten cap. Return drain hose to storage location.
- 5. Fill system with SAE 10W-20 multigrade wide temperature range transmission hydraulic fluid. Reservoir capacity is approximately 10 gal (37.8L).
- 6. Start system and run with tractor at idle and fan turned off for 1-2 minutes. Switch fan to full speed and run with tractor at idle for 1-2 minutes.
- 7. Check reservoir fluid level and fill as required. Hydraulic fluid level should be within 1"-2" from top of reservoir after pump has run and hydraulic hoses have been primed to allow fluid to expand when heated.
- 8. Bring tractor to full PTO speed and adjust flow control for desired system pressure.

NOTE: Periodically check and clean oil coolers.

TRACTOR DRIVEN PTO PUMP AND OIL COOLER OPTION



Hydraulic reservoir

Drain reservoir, clean strainer and change filter annually.


- 1. Disconnect suction line (hose between reservoir and pump) from reservoir and drain. To fully drain tank, raise planter to field raised position.
- 2. Replace filter with good quality 10 micron filter.
- 3. Fill system with SAE 10W-20 multigrade wide temperature range transmission hydraulic fluid. Reservoir capacity is approximately 10 gal (37.8L).
- 4. Start system and run with tractor at idle and fan turned off for 1-2 minutes. Switch fan to full speed and run with tractor at idle for 1-2 minutes.
- 5. Check reservoir fluid level and fill as required. Hydraulic fluid level should be within 1"-2" from top of reservoir after pump has run and hydraulic hoses have been primed to allow fluid to expand when heated.
- 6. Bring tractor to PTO speed and adjust flow control to the desired vacuum level using the flow control valve lever.




Vacuum fan assembly

NOTE: Periodically check and clean oil cooler mounted on vacuum fan housing.

FINGER PICKUP SEED METER INSPECTION/ADJUSTMENT






Removing meter and baffle

Proper finger operation

- Remove two thumbscrews and meter from seed hopper and remove three cap screws and baffle from meter assembly.
- 2. Rotate seed meter drive by hand to ensure springs are holding tabs of fingers against carrier plat and fingers raise in correct area as shown in above photo.



Finger pickup meter parts



Corn Finger Assembly (Position Spring Opening Toward Holder)



Oil Sunflower Finger Assembly


Buildup of debris or chaff may prevent proper finger operation and requires disassembly and cleaning of finger pickup meter.

- 1. Remove cotter pin, cover nut and adjusting nut and wave washer (If applicable) from drive shaft.
- 2. Carefully lift finger holder with fingers and cam off shaft and clean.
- 3. Check brush for wear and replace if necessary or after every 100 acres per row of operation (Approximately 800 acres of corn or sunflowers on a 8 row machine or 1200 acres on an 12 row machine).

NOTE: It is not necessary to remove finger holder to replace brush.

- 4. Remove springs from fingers and remove finger from holder by lifting it out of friction fit slot. Life expectancy of these parts is about 600-900 acres per row of operation under average conditions.
- 5. Reassemble meter in reverse order after cleaning and replacing defective parts. Make sure open end of spring loop is toward inside of finger holder when replacing fingers.
- 6. Install fingers in holder so holder is flush with carrier plate when assembled. A cam projection aligns with a mating notch in bearing housing to ensure proper operation when assembled.


- 7. Check indentations on carrier plate for wear before installing finger holder on carrier plate. Excessive wear of carrier plate at indentations will cause over planting especially with small sizes of seed. Inspect carrier plate annually. Life expectancy should be 250-300 acres per row of operation under average conditions.
- 8. Install wave washer and adjusting nut with finger holder flush against carrier. Tighten adjusting nut to fully compress wave washer. Back off nut ½ to 2 flats to obtain rolling torque of 22 to 25 inch pounds.
- 9. Turn finger holder by hand to make sure it is firmly against carrier plate, but can be rotated with moderate force.



Worn carrier plate

10. Install cover nut and cotter pin. Reinstall baffle.

NOTE: Check adjusting nut tightness on each unit after first day of use and periodically thereafter.







Centering belt housing cover

Remove four cap screws around edge of housing cover and nut from belt idler mounting bolt. Paddles must be correctly oriented as shown above If belt is replaced. A diagram molded into drive sprocket shows correct orientation.

NOTICE


Do not over-tighten hardware or components may be damaged.

Reinstall housing cover. DO NOT TIGHTEN hardware. Wedge a screwdriver between sprocket hub and housing cover as shown above. Pry cover down until centered on belt housing and tighten hardware. Rotate meter drive shaft and check idler alignment. Seed belt should "run" centered on idler or with only slight contact with belt housing or cover.


CLEANING FINGER PICKUP SEED METER FOR STORAGE

- 1. Disassemble meter and blow out any foreign material.
- Wash ONLY in mild soap and water. Do not use gasoline, kerosene, or any other petroleum based product. Dry thoroughly.
- 3. Coat lightly with a rust inhibiter.
- 4. Rotate finger assembly so finger does not touch brush.
- Reassemble and store in a dry, rodent-free location.

BRUSH-TYPE SEED METER MAINTENANCE








Brush-type seed meter parts

Use clean, high quality seed. Damaged or cracked seed, hulls, or foreign materials can become lodged in upper brush and greatly reduce meter accuracy. Remove seed disc daily and check for buildup of foreign material on seed disc, particularly in seed loading slots. Clean disc by washing it with soap and water. Check for cracked seed, hulls, etc. lodged between brush retainer and stainless steel wear band which can greatly reduce accuracy of the meter because upper brush will not be able to retain seed in seed disc pocket. Thoroughly clean brush areas of meter housing.

SEED DISC WEAR

Most seed disc wear is found in the agitation groove area (area between seed loading slots). Wear affects planting accuracy at high RPM. Lay a straight edge across disc surface at agitation groove area and measure gap between disc and straight edge. If agitation groove areas are worn in excess of .030" and accuracy starts to drop off at higher meter RPM, replace seed disc. Estimated seed disc life expectancy under normal operating conditions is approximately 200 acres per row. Severe operating conditions such as dust, lack of lubrication or abrasive seed coating could reduce seed disc life expectancy to under 100 acres per row.




Seed loading slots

STAINLESS STEEL WEAR BAND

NOTICE

If wear band wears through or if meter is used without wear band in place, meter housing may be damaged.

Stainless steel wear band protects meter housing from wear and is .030" thick. Replace wear band when there is approximately .020" of wear in primary wear area. Estimated life expectancy of stainless steel wear band is 240-800 acres per row.




Stainless steel wear band

UPPER BRUSH

Upper brush holds seed in seed disc pocket in seed retention area. Brush must apply enough pressure against seed in seed disc pocket as disc rotates through seed retention area to prevent seed from dropping out of disc pocket. A damaged spot, excessive brush wear, or foreign material lodged in brush may greatly reduce meter performance.

Replace upper brush at 120-400 acres per row of use or sooner if damage or excessive wear is found. Position upper brush into inner perimeter of seed retention area. Make sure base of brush is tight against bottom of meter housing. Install brush retainer and three hex head screws. Tighten screws in sequence shown in photo at right.



Upper brush installation

NOTE: Use GD11122 upper brush retainer for soybean and cotton discs. Use GD8237 upper brush retainer for milo/grain sorghum discs.

LOWER BRUSH

Lower brush moves seed down seed loading slots to seed pockets, isolates seed in reservoir from entering seed tube, and cleans seed loading slots. Estimated lower brush life expectancy is 240-800 acres per row. Replace lower brush if bristles are deformed or missing, or if there are cracks in brush retainer.

CLEANING BRUSH-TYPE SEED METER FOR STORAGE


- Remove meter from seed hopper by removing two thumbscrews securing meter to hopper.
- 2. Remove seed disc and wash with soap and water and dry thoroughly.
- 3. Remove three hex head screws from brush retainer. Remove brush retainer and upper brush.
- 4. Remove three hex head screws from lower brush. Remove lower brush and stainless steel wear band.
- 5. Wash all parts and meter housing with soap and water and dry thoroughly.
- 6. Inspect all parts and replace worn parts.
- 7. Reassemble meter except for seed disc. Store meter in a dry, rodent-free space with seed disc removed.


VACUUM MANIFOLD MAINTENANCE

Dust accumulates in manifolds and hoses during normal operation. Clean manifolds annually. Abnormally dusty planting conditions may require more frequent cleaning.

- 1. Remove vacuum hose from each seed meter.
- Operate vacuum fan at full hydraulic flow from tractor for two minutes to clear manifolds, hoses, and fittings of dust and debris.
- 3. Shut down fan and replace hoses

VACUUM SEED METER MAINTENANCE





Before each planting season inspect seed discs and singulator and clean or replace as needed.

Use clean, high quality seed for maximum meter accuracy. Damaged or cracked seed, hulls, and foreign material may become lodged in seed disc orifices and greatly reduce meter accuracy.

Inspect and clean seed discs daily checking for any buildup of foreign material and blocked orifices. If seed disc orifices are plugged frequently with seed remnants, remnants ejector wheel may need to be replaced. Clean seed disc by washing it with soap and water. Dry thoroughly.

Inspect singulator blades and guide for wear after every 200 acres per row of operation. If adjustment of singulator blade does not affect meter performance or if blades appear worn, singulator blade may need to be replaced.

Replace seed disc or vacuum seal if abnormally high vacuum is required or if consistent operation cannot be achieved.

See "Preparation for Storage" on page 5-37 for additional Vacuum Seed Metering System maintenance.

NOTE: Remove seed discs from meters for annual storage and store them vertically on a dowel or pipe.

SEED METER CLEANOUT


NOTE: Use of damaged seed or seed containing foreign material will cause plugging of seed cell orifices and require more frequent seed meter cleanout to prevent underplanting.

Thorough seed meter cleanout is important to maintain genetic purity.

- 1. Disengage seed drive and remove seed hopper and meter.
- 2. Dump seed from right rear corner of hopper into a container.
- 3. Lay hopper on its right side. Push release button and rotate seed meter vacuum cover clockwise to align keyhole slots with bolt heads. Lift off cover.
- 4. Rotate seed disc hub clockwise to unlock and remove seed disc.
- 5. Empty meter.
- 6. Thoroughly inspect meter to ensure all seed is removed.
- 7. Replace seed disc. Install vacuum cover.


DRAG CLOSING ATTACHMENT


Inspect each drag closing attachment and replace any worn or broken parts before storing planter. Check for loose hardware and tighten as needed.



Drag Closing Attachment

GAUGE WHEEL ADJUSTMENT






Gauge wheel adjustment

Gauge wheels should lightly contact opener blades to prevent accumulation of dirt or trash. Gauge wheels and opener blades should turn with only slight resistance.

Add or remove machine bushings between shank and gauge wheel arm to adjust clearance between gauge wheels and opener blades. Store remaining machine bushings between gauge wheel arm and flat washer on outer side of gauge wheel arm.


NOTE: It may be desirable to space gauge wheel further from blade when operating in sticky soils.

GAUGE WHEEL ARM BUSHING AND/OR SEAL REPLACEMENT



NOTE: Gauge Wheel Arm Bushing and Seal Driver Kit (G1K296) is available through your Kinze Dealer.

- 1. Remove gauge wheel from arm.
- 2. Remove gauge wheel arm from shank assembly.
- 3. Remove seal and bushing and discard. Clean and dry inner bore.



- 4. Drive/press replacement bushing inside bore of arm to a depth of .125" below flush.
- 5. Coat wiping edge of seal with grease.
- 6. Drive/press seal into place with lip to outside.


NOTE: Use extra care to protect the sealing lip during installation. Apply uniform pressure to assemble the seal into the bore of the arm. Never apply a direct hammer blow to the seal surface.

- 7. Inspect gauge wheel pivot spindle.
- Reinstall gauge wheel arm assembly and gauge wheel.


NOTE: Use special machine bushing between gauge wheel arm and gauge wheel.

- 9. Shim for proper gauge wheel tire/disc blade clearance.
- 10. Lubricate with an SAE multipurpose grease.

GAUGE WHEEL ARM PIVOT SPINDLE RE-PLACEMENT




- 1. Remove gauge wheel and arm assemblies from shank assembly.
- 2. Remove ½" x ¾" cap screw that locks pivot spindle in place and remove spindle.



Pivot spindle cap screw

3. Install replacement spindle and position as shown below. Exact centering is critical.



- 4. Install ½" x ¾" cap screw and torque to lock pivot spindle in place.
- 5. Install gauge wheel and arm assemblies. Shim for proper gauge wheel tire/disc blade clearance.

15" SEED OPENER DISC BLADE/ BEARING ASSEMBLY


Approximately 1" \pm ½" of blade-to-blade contact should be maintained to properly open and form seed trench. As blade diameter decreases due to wear, it is necessary to relocate machine bushings from inside to outside to maintain 1" \pm ½" of contact.

NOTE: Proper blade clearance is critical. Blades should have 1" \pm ½" contact in this area. When blades are turned by hand in opposite directions against each other, there should be only light resistance to turning. Re-adjust blade scraper if necessary to center it between the blades.

NOTE: If proper blade-to-blade contact cannot be maintained after relocating machine bushings or if blade diameter wears below 14½", blades should be replaced.

NOTICE

Excessive blade contact may result in premature disc opener bearing/hub failures and excessive wear on seed tube guard/inner scraper. When properly adjusted, if one blade is held in fixed position, opposite blade should rotate with less than 5 pounds force at outer edge of blade.



REPLACE DISC BLADE/BEARING ASSEMBLY

- 1. Remove gauge wheel.
- 2. Remove scraper.
- 3. Remove bearing dust cap.
- Remove cap screw, washer and disc blade/bearing assembly. Machine bushings between shank and disc blade are used to maintain approximate 1" ± ½" of blade-to-blade contact.

NOTICE

Left hand side of opener uses a left hand threaded cap screw. DO NOT OVER TIGHTEN. Damage to shank threads require replacement of row unit shank assembly.

 Install machine bushing(s), new disc blade bearing assembly, washer and cap screw.
 Torque 5%"-11 Grade 5 cap screw to value shown in "Torque Values Chart".

NOTE: Replace disc blades only with disc blades of equal thickness.

- 6. Replace bearing dust cap.
- 7. Install scraper.
- 8. Install gauge wheel.

It may be necessary to replace bearing only if there is excessive endplay or if bearing sounds or feels rough when disc blade is rotated.

REPLACE BEARING ONLY


- Remove gauge wheel, scraper, bearing cap, cap screw, washer and disc blade/bearing assembly.
- 2. Remove ¼" rivets from bearing housing to expose bearing.
- 3. After installing new bearing, install three evenly spaced ¼" cap screws into three of six holes in bearing housing to hold bearing and bearing housing in place. Install rivets in other three holes. Remove ¼" cap screws and install rivets in those three holes.
- Reinstall disc blade/bearing assembly, washer and cap screw. Torque 5/8"-11 cap screw to value shown in "Torque Values Chart" at the beginning of this section.
- 5. Replace bearing dust cap.
- 6. Install scraper and gauge wheel.

SEED TUBE GUARD/INNER SCRAPER

Seed tube guard protects seed tube and acts as inner scraper for seed opener disc blades.

Remove seed tube and check for wear. Excessive wear on seed tube indicates a worn seed tube guard. Replace seed tube guard if it measures 5%" or less at lower end. A new seed tube guard measures approximately 7%".

NOTE: No till planting or planting in hard ground conditions, especially when planter is not equipped with no till coulters, and/or excessive blade-to-blade contact increases seed tube guard wear and requires more frequent inspection and/or replacement.



Seed tube guard/inner scraper (Gauge wheel/seed opener disc blade removed

NOTICE

Over tightening hex socket head cap screws may damage shank threads and require replacement of shank. An excessively worn seed tube guard may allow blades to wear into row unit shank, also requiring replacement of shank.


Remove seed tube and two hex socket head cap screws that attach seed tube guard. Hold replacement seed tube guard centered between seed opener disc blades. Install hex socket head cap screws. DO NOT TIGHTEN. Using a clamp or vise-grip, squeeze opener blades together in front of seed tube guard. Tighten seed tube guard retaining screws. Remove clamps. Distance between seed tube guard and opener blades should be equal on both sides. Reinstall seed tube.

FRAME MOUNTED COULTER

NOTE: Torque %" spindle hardware to 120 ft-lb (162.7 N-m)

See "Frame Mounted Coulter" in Row Unit Operation section of this manual for depth and spring adjustment.


Replace 16" diameter coulter blade (1" fluted, 1" bubbled or ¾" fluted) when worn to 14½" (maximum allowable wear).



Frame mounted coulter spindle

RESIDUE WHEELS (FOR USE WITH FRAME MOUNTED COULTER)

Wheel hub is equipped with sealed bearings. Replace bearings if a bearing sounds or feels rough when wheel is rotated.



Frame mounted coulter residue wheels


ROW UNIT MOUNTED DISC FURROWER

Lubricate bushings in support arm mounting bracket at frequency indicated in Lubrication of this section. Check each bolt for proper torque. If bolt is loose, it should be removed and bushing inspected for cracks and wear. Replace bushings as necessary.

NOTE: Use only hardened flat washers. Replace damaged flat washers with proper part. Torque bolts to 130 ft-lb (176.2 N-m).

Blade hubs are equipped with sealed bearings. Replace bearings if a bearing sounds or feels rough when wheel is rotated.

Replace solid or notched 12" diameter blades when worn to 11".




Row unit mounted disc furrower

ROW UNIT MOUNTED BED LEVELER

Lubricate bushings in mounting bracket and links at frequency indicated in Lubrication of this section. Check each bolt for proper torque. If bolt is loose, it should be removed and bushing inspected for cracks and wear. Replace bushing if necessary.

NOTE: Use only hardened flat washers. Replace damaged flat washers with proper part. Torque bolts to 130 ft-lb (176.2 N-m).



Row unit mounted bed leveler

ROW UNIT MOUNTED NO TILL COULTER

Check nuts and hardware periodically for proper torque. Be sure coulter is positioned square with row unit and aligned in front of row unit disc opener.

NOTE: Torque %" spindle hardware to 120 ft-lb (162 N-m).

Coulter blade can be adjusted to one of four settings. Initially blade is set in highest position. As blade wears it can be adjusted to one of three lower settings. See "Row Unit Mounted No Till Coulter" in Row Unit Operation section of this manual.


Replace 16" diameter coulter blade when worn to 141/2".



Row unit mounted no till coulter

SPIKED CLOSING WHEEL

Inner parts of spiked closing wheel will begin to wear at approximately 70% of life. Flip/reverse wheel to utilize remaining life of wheel.



Row Unit Spiked Closing Wheel

COULTER MOUNTED RESIDUE WHEELS


Wheel hubs are equipped with sealed bearings. If bearings sound or feel rough when wheel is rotated, replace them.



Coulter mounted residue wheels

ROW UNIT MOUNTED RESIDUE WHEEL

Wheel hub is equipped with sealed bearings. If a bearing sounds or feels rough when wheel is rotated, replace them.




Row unit mounted residue wheels

GRANULAR CHEMICAL ATTACHMENT

Before storing planter, disengage granular chemical drive by rotating throwout knob ¼ turn counterclockwise. Remove drive chain and empty and clean all granular chemical hoppers. Clean drive chains and coat them with a rust preventive spray or submerge chains in oil. Inspect and replace worn or broken parts.

Install hoppers and chains. Check chain alignment.



Granular chemical throwout knob

SPRING TOOTH INCORPORATOR

Before storing planter, inspect each spring tooth incorporator and replace worn or broken parts. Check for loose hardware and tighten as needed.



Spring tooth incorporator

CHECK VALVE (LIFT SYSTEM)

Check valves, located in valve block on right side of center post, trap oil flow in planter's lift system to keep toolbar level during field operation. Consult your Kinze Dealer for service.



CHECK VALVE (VACUUM FAN)

Check valve located in valve block below vacuum fan motor assembly operates as a return line check to prevent vacuum fan motor reverse operation. Remove and inspect valve If it does not operate properly. Check for foreign material and if O-ring is leaking internally. Replace if defective.



FLOW CONTROL VALVE

Flow control valves should be adjusted for row marker raise and lower speed as part of assembly procedure or upon initial operation. If valve fails to function properly or requires frequent adjustment, it should be removed for inspection. Check for foreign material and contamination on valve and seating areas of valve body. Replace defective components.




PRESSURE RELIEF VALVE

If pressure relief valve does not release tongue lock or function properly, remove valve from valve block and check for foreign material or if O-ring is leaking internally. Replace if defective.



PRESSURE REDUCING RELIEF VALVE

If wings do not properly stay to ground, plumb into butt end of cylinder to test psi. Proper setting is 2000 PSI.



NOTICE

Connect hydraulic motor case drain to a case drain return line with zero pressure on tractor or hydraulic motor will be damaged. DO NOT connect hydraulic motor case drain to SCV outlet. Contact tractor manufacturer for specific details on "zero pressure return".

RELIEF VALVE CARTRIDGE


Pressure relief valve located in valve block below vacuum fan motor assembly helps prevent damage to vacuum fan motor by limiting pressure in the motor case drain line. It is set to open at 35 PSI. If valve fails to function properly, it should be removed for inspection. Check for foreign material and contamination on valve and the seating area of valve body. Replace if defective.




SOLENOID VALVE

Solenoid valve consists of a chambered body with an electric coil actuated cartridge valve.

If solenoid or solenoids fail to operate, first determine if problem is electrical or hydraulic. If valve is working properly, a click will be heard when solenoid coil is energized and valve stem opens. If no sound is heard, check solenoid coil by touching top of coil housing with a metallic object such as a pliers or screwdriver. If coil is working properly, coil housing will be strongly magnetized when energized. If voltage to coil is low it will be weakly magnetized when energized and no click will be heard.



ROW MARKER BEARING LUBRICATION OR REPLACEMENT




- 1. Remove retainer and marker blade.
- 2. Remove dust cap from hub.
- Remove hub shield. Note direction of installation.
- Remove cotter pin, slotted hex nut, and washer.
- 4. Slide hub from spindle.
- 5. Remove bearings and cups and discard if bearings are being replaced. Clean hub and dry. Remove bearings only and not cups if repacking.
- 6. Press in new bearing cups with thickest edge facing in. (Bearing replacement procedure only.)
- 7. Pack bearings with heavy duty wheel bearing grease thoroughly forcing grease between roller cone and bearing cage. Fill the space between the bearing cups in the hub with grease.
- 8. Install rubber seal into grease seal. Place inner bearing in place and press in new rubber seal/grease seal.
- 9. Clean spindle and install hub.
- 10. Install outer bearing, washer and slotted hex nut. Tighten slotted hex nut while rotating hub until there is some drag. This ensures all bearing surfaces are in contact. Back off slotted nut to nearest locking slot and install cotter pin.
- 11. Fill dust caps approximately ¾ full of wheel bearing grease and install on hub.
- 12. Install hub shield.
- 13. Install marker blade and retainer on hub. Tighten hardware evenly.

ROW MARKER TRANSPORT STAND ADJUSTMENT


Row marker transport stands must be correctly adjusted to allow marker cushion cylinders to function properly.

- 1. Raise markers to transport position.
- 2. Loosen mounting hardware to allow transport stands to drop down or remove transport stands.
- 3. With tractor engine shutoff, release hydraulic pressure on marker cylinders.
- Locate transport stands so marker arm rests lightly on transport stand. When transport stands are correctly adjusted pin at rod end of cylinder should be loose enough to rotate and move back and forth in mounting slot.



Row marker transport stand

WHEEL BEARING REPACK OR REPLACEMENT



- 1. Raise tire clear of ground and remove wheel.
- 2. Remove double jam nuts and slide hub from spindle.
- 3. Remove bearings and cups and discard if bearings are being replaced. Clean hub and dry. Remove bearings only and not cups if repacking.
- 4. Press in new bearing cups with thickest edge facing in. (Bearing replacement procedure only.)
- Pack bearings with heavy duty wheel bearing grease thoroughly forcing grease between roller cone and bearing cage. Fill space between bearing cups and hub with grease.
- 6. Place inner bearing in place.
- 7. Clean spindle and install hub.
- 8. Install outer bearing and jam nut. Tighten jam nut while rotating hub until there is some drag. This ensures all bearing surfaces are in contact. Back off jam nut ¼ turn or until there is only slight drag when rotating hub. Install second jam nut to lock against first.
- Install wheel on hub. Tighten hardware evenly.




Uncontrolled machine movement can crush or cause loss of control resulting in death, serious injury, or damage to property and equipment. Install all safety lockup devices before working under or transporting this equipment.

CENTER FRAME WEAR PADS


The 3660 planter includes a center frame section that slides up and down on a central 7" x 7" tube to move between transport and operation positions. Part of the center frame is a slide assembly consisting of four wear pad assemblies held in place by 3/4" set screws and jam nuts, riding against a powder coated center tube.

Inspect and adjust wear pads annually to ensure planter frame is stable and planter tracks correctly. Wear pads should lightly make full contact with center post when properly adjusted. Excessive preload on pads will cause increased hydraulic lift pressure and may fail to lift planter when fully loaded.

ROCKSHAFT TO HITCH SHIM ADJUSTMENT



26" strap fixture




Wear plate an shim installation

- 1. Install strap fixture at rockshaft cylinder location to establish 26" center-to-center cylinder mount distance.
- 2. Place ¼" thick wear plate between cylinder mount bracket and lower cylinder mount. Install a shims under wear plate using 16 and 10 gauge shims to maintain 26" distance.


CENTER FRAME RELATION TO INNER HITCH ADJUSTMENTS

NOTE: Planter must be in transport position with safety lockup installed and rock shaft cylinders fully retracted.

1. Lock wing frames for transport, fully raise planter, and install safety lockup. Make sure top latch is around cylinder rod and fastened with safety pin and that lower end is secured with detent pin.



Lower front and side - six set screws



Lower rear side - two set screws

2. Adjust lower wear pads. Loosen jam nuts. Loosen and tighten set screws to move center frame slide tube until distance from outside of center tube to outside of slide tube is equal on all four sides - approximately 1½". Tighten all eight set screws.

NOTE: Perform Step 3 one set screw at a time.


- 3. Set contact pressure of lower wear pads. Loosen set screw, then tighten to 20 ft-lb (27.1 N-m). Hold set screw with a wrench to prevent it from turning and tighten jam nut to 75 ft-lb (101.6 N-m). Repeat with remaining set screws.
- 4. Remove safety lockup and lower planter frame until approximately 2' above top surface of outer hitch. Turn off hydraulic power source.

Top surface of outer hitch must be parallel to bottom of center frame. Distance between them is measured at four points:

- Top front of inner hitch to bottom of center sub-frame left and right sides.
- Top rear of inner hitch to bottom of center frame left and right sides.

NOTE: Subtract 8" from front measurement values before comparing to rear values.

- 5. Place a 2" x 2" x 36" tube or similar straight object on top of one leg of inner hitch, behind shim stack as shown at right.
- 6. Measure at points as shown at right.
- 7. Repeat on other leg of inner hitch.




Measurement locations

- 8. Loosen jam nuts. Loosen and tighten set screws until all four measurements in Step 5 7 are equal.
- 9. Tighten all eight set screws.


NOTE: Perform Step 10 one set screw at a time.

 Set contact pressure of upper wear pads. Loosen set screw, then tighten to 20 ft-lb (27.1 N-m). Hold set screw with a wrench to prevent it from turning and tighten jam nut to 75 ft-lb (101.6 N-m). Repeat with remaining set screws.




Upper set screws

Some shims must be removed to preventing pre-loading of planter frame in preparation of adjusting shim stack thicknesses.




Inner hitch shim stacks



Field stabilizer shim stack

- 11. Loosen fasteners and remove one or two shims from the following locations:
 - Inner hitch shim stack left and right sides.
 - Field stabilizer shim stack left and right sides.
- 12. Replace fasteners at field stabilizers to keep shim stack in place.
- Raise landing pad bolts to prepare for adjusting shim stack thickness. Loosen jam nuts and thread in bolts several turns.



Landing pad bolts

- 14. Make two 3/16" x 2" x 1" shims out of bar stock or other suitable material.
- 15. Place one shim on left and one shim on right side of center post flange. Lower planter until center frame slide rests on them.

NOTE: When planter is lowered, no planter frame weight is to be supported at shim stacks or landing pad bolts – there must be space for adding shims and adjusting bolts downward.



3/16" x 2" x 1" shim

NOTE: Completely fill open space with appropriate combination of shims. Tolerance for filling open space is +0.030"/-0.000".


- 16. Add shims to fill open space at the following locations:
 - Inner hitch shim stack left and right sides; make sure 1/4" thick wear plates remain on top.
 - Field stabilizer shim stack left and right sides.
- 17. After adding shims, shim stack fasteners on inner hitch may be tightened. DO NOT fully tighten fasteners at field stabilizers.
- 18. Raise planter on center post. Remove temporary shims from beneath center frame slide and fully lower planter.
- 19. Lower landing pad bolts until they touch landing pad. Hold in place with wrench to prevent turning and tighten jam nuts.

TRIANGULATE AND SET PLANTER SQUARENESS

NOTICE


Planter frame must be square with hitch frame to ensure planter tracks correctly during operation.


- Raise planter to transport position and install safety lockup.
- Loosen fasteners and remove rotation stop tap block and shims.
- 3. Remove safety lockup and fully lower planter.



Rotation stop tap block and shims

- Measure 67" from left side of inner hitch along lower frame member of center frame; place reference mark with an appropriate marker. Repeat on right side.
- Measure width of inner hitch, divide value by 2, measure from one side of hitch, and place a centerline reference mark at that point on upper hitch cross member.
- Measure from centerline to each of the reference marks on center frame (Y"). If measurements are NOT equal go to next step. If measurements are equal skip to Step 8.
- Rotate center post or push on end of planter frame with shorter distance. Re-measure from centerline to reference marks. Repeat until measurements are equal.
- Tighten field stabilizer fasteners when measurements are equal on both sides of planter.






Field stabilizer

INSTALL ROTATION STOP BLOCK

- 1. Raise planter to transport position and install safety lockup.
- Measure distance between stop mount on inner hitch and stop surface on center post. Include stop tap block to determine required combination of shims to completely fill this space. Tolerance for filling the space is +1/16"/-0".




Stop block measurement

Rotate center post slightly to provide room to install shims.

NOTE: In situations where few shims are required, attachment cap screws may protrude beyond stop tap block. Install shims beneath cap screw heads to prevent them from protruding.

- Attach required shims and stop tap block using two 3/8"-16 x 3" cap screws.
- 5. Rotate center post against stop tap block.



Stop tap block installation


INSPECT AND ADJUST ROTATION CYLINDER MOUNT

 Make sure center post is rotated against stop block. Inspect rotation cylinder for correct amount of retraction.

A correctly retracted cylinder will have 1/16" or less exposed sliding surface on the rod .

If cylinder has more than 1/16" sliding surface exposed, shims will need to be removed from cylinder mount.

If cylinder has no slide surface exposed, AND center post cannot be fully rotated against stop block, shims will need to be added to cylinder mount.



Rotate Cylinder mount adjustment


- 2. Disconnect rod end of cylinder and remove six sets of fasteners from cylinder mount. Add or subtract shims as necessary.
- 3. Reassemble cylinder mount and connect rod end of cylinder. Inspect for correct amount of retraction.

PNEUMATIC DOWN PRESSURE AIR COMPRESSOR TANK


The air tank is located in the frame. Moisture should be drained daily from the tank. Tank should be drained completely for storage.

To drain tank, locate drain plug on the bottom of tank. Stand off to the side of tank and pull cable attached to drain.

NOTE: If mositure is not drained from tank rust particles will form inside tank.



FERTILIZER CHECK VALVE CLEANING AND REPAIR



- 1. Unscrew valve body and separate halves. Note direction and location of parts.
- 2. Clean and inspect parts. Flush with clean water. Replace damaged parts.
- 3. Reassemble exactly as shown. O-ring and valve seat must be firmly in place inside each half of valve body.

PISTON PUMP STORAGE



Liquid fertilizer piston pump

NOTICE

Entrance of air into pump will cause rapid and severe corrosion. KEEP AIR OUT OF PUMP!

NOTE: SUSPENSION FERTILIZER must be flushed from pump for ANY storage period.

- 1. Flush pump with 5 to 10 gallons of fresh water and circulate until all corrosive salts are dissolved in pump.
- 2. Set pump on 10. Draw in a mixture of half diesel fuel and 10 weight oil until discharge is clean. Plug inlet and outlet.

PREPARATION FOR STORAGE

Store planter in a dry sheltered area if possible.

Remove all trash wrapped on sprockets or shafts and remove dirt that can draw and hold moisture.

Clean all drive chains and coat with a rust preventative spray, or remove chains and submerge in oil.

Lubricate planter and row units at all lubrication points.

Inspect planter for parts that in need of replacement and order during "off" season.

Make sure all seed and granular chemical hoppers are empty and clean.

Remove seed discs from seed meters, clean and store meters in a rodent-free, dry area with discs removed. Store seed discs vertically on a dowel or pipe.

Remove vacuum hose from each seed meter. Operate vacuum fan at full hydraulic flow from tractor for two minutes to clear manifolds, hoses and fittings of dust and debris.

Clean breather on analog vacuum and pressure gauges.

Disassemble, clean and grease all U-joint slides.

Grease or paint disc openers/blades and row marker disc blades to prevent rust.

Flush liquid fertilizer tanks, hoses and metering pump with clean water. See "Piston Pump Storage" if applicable.

Empty dry fertilizer hoppers. Clean hoppers. Disassemble and clean metering augers. Reassemble, coating all metal parts with rust preventative.

Bulk Fill System:

- Clean out bulk fill hopper, entrainment assembly, and delivery hoses.
- Disconnect delivery hoses from entrainer ports. Install small orange caps onto ports. Attach hoses to caps.
- Disconnect delivery hoses from air dissipator at each row unit. Install large orange caps. Attach hoses to caps.
- Check all bolts and fasteners used to assemble and attach entrainment device are tight (if applicable).
- Loosen knobs on entrainer cleanout doors to remove pressure from door gaskets.
- Inspect all seed delivery hoses and replace any that are worn, cut, or cracked.




Entrainer cap




Air dissipator cap

ELECTRICAL WIRING DIAGRAM FOR LIGHT PACKAGE

Machines with double light assemblies







^{*} Optional customer-supplied auxiliary lights and wires may be wired into existing plug terminals.

Model 3660 Twin-Line Planter safety light package meets ASAE Standards. Check with your tractor manufacturer for proper connection to your tractor.

ELECTRICAL CONTROL CONSOLE SCHEMATIC


NOTE: Disconnect control console from tractor battery before doing any electrical work. Keep wiring harnesses away from high temperature areas or sharp edges. DO NOT route wiring harnesses along battery cables. Use cable ties to keep wire harness away from moving parts on tractor and planter. Be sure tractor frame ground connections are clean to provide good electrical contact.






Rear View of Front Panel


ELECTRICAL WIRING HARNESS SCHEMATIC (On Tractor)



ELECTRICAL WIRING HARNESS SCHEMATIC (On Planter)




VALVE BLOCK - LOCATED ON HITCH



- 1. BLACK/RED Pin "C" (Ground)
- 2. BLUE/RED Pin "B" (Rotate) Port V9
- 3. BLUE/RED Pin "B" (Rotate) Port V12
- 4. ORANGE/RED Pin "A" (Tongue) Port V10
- 5. ORANGE/RED Pin "A" (Tongue) Port V13
- 6. ORANGE/RED Pin "A" (Tongue) Port V14

VALVE BLOCK - LOCATED ON REAR CENTER FRAME





- 1. YELLOW/RED Pin "F" (Wing Lock) Ports V3 & V4
- 2. RED Pin "O" (R.H. Marker) Ports V2 & V10
- 3. BLUE Pin "H" (L.H. Marker) Ports V1 & V9
- 4. BLUE/BLACK Pin "V" (Raise To Transport) Ports V6 & V5
- 5. BROWN Pin "R" (L.H. Point Row Clutch)
- 6. YELLOW Pin "S" (L.H.Two-Speed Clutch)
- 7. ORANGE Pin "G" (R.H. Point Row Clutch)
- 8. RED/BLACK Pin "U" (R.H. Two-Speed Clutch)
- 9. BLACK (Monitor Ground) Port V3


HYDRAULIC SYSTEM SCHEMATIC

16 Row Shown (Two Wing Lift Cylinders Per Wing)

12 Row (One Wing Lift Cylinder Per Wing)











HYDRAULIC SYSTEM SCHEMATIC (Continued)

- 16 Row Shown (Two Wing Lift Cylinders Per Wing)
- 12 Row (One Wing Lift Cylinder Per Wing)












HYDRAULIC SCHEMATIC - VACUUM FAN MOTOR SYSTEM



HYDRAULIC SCHEMATIC - VACUUM FAN MOTOR SYSTEM WITH BULK FILL SYSTEM





HYDRAULIC SCHEMATIC - OPTIONAL TRACTOR DRIVEN PTO PUMP AND OIL COOLER SYSTEM



Failure to connect to a return with zero pressure will damage hydraulic motor. Connect hydraulic motor case drain to a case drain return line with zero pressure on tractor. DO NOT connect hydraulic motor case drain to SCV outlet. Contact tractor manufacturer for specific details on "zero pressure return".

HYDRAULIC SCHEMATIC - OPTIONAL PTO PUMP DRIVE AND OIL COOLER SYSTEM (PLANTER MOUNTED)







NOTICE

Failure to connect to a return with zero pressure will damage hydraulic motor. Connect hydraulic motor case drain to a case drain return line with zero pressure on tractor. DO NOT connect hydraulic motor case drain to SCV outlet. Contact tractor manufacturer for specific details on "zero pressure return".

ELECTRIC CLUTCH SCHEMATIC






ISOBUS CAN JUMPER CABLE




SIGNAL	CAN	WIRE/COLOR
CAN H	1	Twisted Pair Yellow
CAN L	2	Twisted Pair Green

PRODUCT CONTROL MODULE CABLE




Signal	PCM	Wire/Color	J1	J2	CAN	RC	CC	IS	G
Load Power	1	Red	2	-	-	-	-	-	-
Load Power	2	Red	3	-	-	1	-	-	-
Load Power	3	Red	4	-	-	-	-	-	-
Load Power	4	Red	5	-	-	-	-	1	-
Load Ground	5	Black	-	-	-	-	-	-	1, 2
Load Ground	6	Black	14, 15	-	-	-	-	-	-
Load Ground	7	Black	16	-	-	2	-	-	-
Load Ground	8	Black	17	-	-	-	-	-	-
ECU Power	11	White/Red	11	-	-	-	-	-	-
CAN H	-	Twisted Pair Yellow	34	-	1	-	-	-	-
CAN L	-	Twisted Pair Green	33	-	2	-	-	-	-
Switch In	-	Red/Green	10	-	-	-	-	2	-
Section 1	-	White	24	-	-	-	1	-	-
Section 2	-	Green	25	-	-	-	2	-	-
Section 3	-	Orange	26	-	-	-	3	-	-
Section 4	-	Blue	27	-	-	-	4	-	-
Section 5	-	Brown	-	11	-	-	5	-	-
Section 6	-	Yellow	-	10	-	-	6	-	-
Section 7	-	Violet	-	9	-	-	7	-	-
Section 8	-	Gray	-	8	-	-	8	-	-
Section 9	-	Pink	-	7	-	-	9	-	-
Section 10	-	Tan	-	6	-	-	10	-	-
Section 11	-	Red/Green	-	5	-	-	11	-	-
Section 12	-	Black/Red	-	4	-	-	12	-	-
PWM 1 Power	-	Red/White	-	23	-	3	-	-	-
PWM 1 Ground	-	Black/White	35	-	-	4	-	-	-
PWM 2 Power	-	Red/Yellow	-	12	-	5	-	-	-
PWM 2 Ground	-	Black/Yellow	12	-	-	6	-	-	-
PWM 3 Power	-	Red/Blue	1	-	-	7	-	-	-
PWM 3 Ground	-	Black/Blue	-	24	-	8	-	-	-
Meter Speed 1	-	Green	30	-	-	9	-	-	-
Meter Speed 2	-	Green/White	29	-	-	10	-	-	-
Meter Speed 3	-	Green/Red	-	33	-	11	-	-	-

IMPLEMENT SWITCH EXTENSION CABLE




Signal	Imp. Switch 1 WP Tower 1	Imp. Switch 2 WP Tower 2	Motion Sensor WP Shroud	Color	Clutch Module Molex Recept	Seed Rate Module Deutcsch Plug	Ground Splice 1	Ground Splice 2	Gauge
12V+ Power	Α	А	-	Brown	1	12	-	-	16
Switch Signal	В	В	-	Green	2	10	-	-	16
Motion Signal	-	-	С	White	-	11	-	-	16
Ground	-	-	В	Black	-	6	-	-	16
12V+ Power	-	-	Α	Red	-	1	-	-	16
Ground	C (Blue 16 AWG)	C (Blue 16 AWG)	-	Black	-	-	2	2	12
12V+ Power	-	-	-	Red	-	-	1	1	12

SECTION ADAPTER CABLE - 12 ROW




Signal	Color	AMP 1 (Left)	AMP 2 (Right)	Molex	D1	D2
High Current Power	Red	1 (16 Gauge)	1 (16 Gauge)	-	1 (12 Gauge)	1 (12 Gauge)
Ground	Black	-	-	-	2	2
Row 1, 2	Black	2, 3	-	1	-	-
Row 3, 4	Brown	4, 5	-	2	-	-
Row 5, 6	Orange	6, 7	-	3	-	-
Row 7, 8	Pink	-	6, 7	4	-	-
Row 9, 10	Green	-	4, 5	5	-	-
Row 11, 12	Yellow	_	2, 3	6	-	-


SECTION ADAPTER CABLE - 16 ROW



Signal	Color	AMP 1 (Left)	AMP 2 (Right)	Molex	D1	D2
High Current Power	Red	1 (16 Gauge)	1 (16 Gauge)	-	1 (12 Gauge)	1 (12 Gauge)
Ground	Black	-	-	-	2	2
Row 1, 2	Black	2, 3	-	1	-	-
Row 3, 4	Brown	4, 5	-	2	-	-
Row 5, 6	Orange	6, 7	-	3	-	-
Row 7, 8	Pink	8, 9		4	-	-
Row 9, 10	Green	-	8, 9	5	-	-
Row 11, 12	Yellow	-	6, 7	6	-	-
Row 13, 14	Blue	-	4, 5	7	-	-
Row 15, 16	Violet	-	2, 3	8	-	-

CLUTCH CABLE - 12 ROW







Row 2/15 Row 1/16	∢	В		ı		,	,	ı	
Row 2/15	∢		В		ı		ı		•
Row 3/14	∢	ı		В		ı		ı	,
Row 4/13	∢	ı	ı	ı	Ф	ı	ı	ı	
11 Row 5/12 Row 4/13 Row 3/14 Ro	∢		•		•	В	•	ı	
30w 6/	∢	ı		ı		ı	Δ	ı	,
Row 7/10 F	∢		ı		•		ı	В	•
Row 8/9	∢	ı	ı	ı		ı		ı	Ф
Clutch Cable Row 8/9	_	2	က	4	2	9	7	80	o
Signal	Power	Row 1/16	Row 2/15	Row 3/14	Row 4/13	Row 5/12	Row 6/11	Row 7/10	Row 8/9

Clutch Module Left/Right

CLUTCH CABLE - 16 ROW







BULK FILL

PROBLEM	POSSIBLE CAUSE	SOLUTION
Seed does not travel through delivery tubes.	System pressure set too low.	Increase system pressure.
Seed stops flowing to row unit during planting.	Seed surging.	Shut down bulk fill system and restart system from idle seed should start flowing.
	Debris in system.	Insert shutoff door, open cleanout door. remove plug.
Seed does not move from entrainer at startup after exposure to water.	Seed swelled in entrainer.	Insert shutoff door, open cleanout door. remove swelled seed.

CLOSING WHEEL

PROBLEM	POSSIBLE CAUSE	SOLUTION
Closing wheel(s) leave severe imprint in soil.	Too much closing wheel down pressure.	Adjust closing wheel pressure.
Closing wheel(s) not firming soil around seed.	Not enough closing wheel down pressure.	Adjust closing wheel pressure. Severe no till conditions may require use of cast iron closing wheels.
"V" closing wheel running on top of seed furrow.	Improper centering.	Align. See "V Closing Wheel Adjustment".
Single closing wheel not directly over seed.	Improper centering.	Align. See "Covering Discs/Single Press Wheel Adjustment".

LIFT CIRCUIT TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
Right wing raises faster than left wing. Right wing may even raise completely before rock shaft and left wing start to raise. If planter is loaded, rock shaft and left wing may not be able to raise at all.	Master cylinder, located on right side of rock shaft, leaking internally. NOTE: Make sure lift system is completely rephased.	Repair master cylinder.
Left wing raises faster than right wing. Left wing may even raise completely before rock shaft and right wing start to raise. If planter is loaded, rock shaft and right wing may not be able to raise at all.	Master cylinder, located on left side of center post, leaking internally. NOTE: Make sure lift system is completely rephased.	Repair master cylinder.
Rock shaft will raise, but wings do not.	Planter hydraulic circuit out of phase. Usually occurs when planter is lowered from transport position.	Hold hydraulic control in lowering position to give hydraulic circuit more time to rephase.
Planter will not raise or raises slowly.	Tractor may have hydraulic problem.	Switch remote outlets being used. Repair tractor hydraulics.
	Planter may be overloaded with hopper extensions and/or extra fertilizer tanks, coulters or other non-Kinze attachments.	Remove weight.
Planter will not rephase.	All cylinders not completely retracted. Caused by mechanical interference on or between planter frame and wheel lift module.	Remove interference.
	Center cylinders not retracting completely.	Lower planter and hold hydraulic lever in lower position to rephase system. Lower cylinder pins must be free to rotate in this position. If pins are tight, adjust cylinder clevises.

PISTON PUMP

PROBLEM	POSSIBLE CAUSE	SOLUTION
Pump hard or impossible to	Valves fouled or in wrong place.	Inspect and clean valves.
prime.	Air leak in suction line.	Repair leak.
	Pump set too low.	Adjust pump setting.
	Packing washers worn out.	Replace.
Low metering.	Valves fouled or in wrong place.	Inspect and clean valves.
	Air leak in suction line.	Repair leak.
	Pump set too low.	Adjust pump setting.
	Broken valve spring.	Replace spring.
Over meters.	Broken discharge valve spring.	Replace spring.
	Trash under valves.	Inspect and clean valves.
	Improper rate setting.	Adjust pump setting.
Leaks through when stopped.	Broken discharge valve spring.	Replace spring.
	Trash under valves.	Inspect and clean valves.
Fertilizer solution leaking under stuffing box.	Packing washers worn out.	Replace.
Pump using excessive oil.	Oil seals or O-ring worn and leaking.	Replace.
Pump operates noisily.	Crankcase components worn excessively.	Inspect and replace if necessary.

PTO PUMP DRIVE AND OIL COOLER OPTION

PROBLEM	POSSIBLE CAUSE	SOLUTION	
Pump is squealing.	Lack of oil to pump.	Check for plugged suction strainer. Check oil level.	
Oil temperature is high.	Low oil level.	Check oil level and add as required.	
Desired fan speed cannot be	Low oil level.	Check oil level and add as required.	
achieved.	Plugged filter.	Check and change as required.	
Vacuum level not displayed.	Digital vacuum gauge console power OFF.	Turn ON.	
	Cable not plugged in.	Check connection.	
	Digital vacuum gauge console has no power.	Check fuse.	

ROTATION CIRCUIT

PROBLEM	POSSIBLE CAUSE	SOLUTION
Cylinder does not extend, but will retract.	Solenoid valve coil in port V12 defective.	Switch coil from port V12 with coil in port V9. If cylinder extends but will not retract, replace defective coil from port V12.
	Solenoid valve cartridge in port V12 stuck closed.	Switch cartridge from port V12 with cartridge in port V9. If cylinder extends but will not retract, replace defective cartridge from port V12.
Cylinder does not retract, but will extend.	Solenoid valve coil in port V9 defective.	Switch coil from port V9 with coil in port V12. If cylinder extends but will not retract, replace defective coil from port V9.
	Solenoid valve cartridge in port V9 stuck closed.	Switch cartridge from port V9 with cartridge in port V12. If cylinder extends but will not retract, replace defective cartridge from port V9.

ROW MARKER OPERATION

PROBLEM	POSSIBLE CAUSE	SOLUTION
Right marker lowering slower than left marker.	Solenoid valve cartridge in port V1 not opening completely.	Switch with cartridge in port V2. If problem repeats, replace cartridge.
	Hose pinched or collapsed.	Inspect hose routing. Replace or repair hoses as required.
Left marker lowering slower than right marker.	Solenoid valve cartridge in port V2 not opening completely.	Switch with cartridge in port V1. If problem repeats, replace cartridge.
	Hose pinched or collapsed.	Inspect hose routing. Replace or repair hoses as required.
Both markers lowering.	Solenoid valve cartridge stuck open. If left marker switch is selected, right cartridge (V1) is defective. If right marker switch is selected, left cartridge (V2) is defective.	Replace solenoid valve cartridge.
Neither marker lowers.	Blown fuse.	Check red light on control console. It should be on if switch is on. If light is not on, switch to opposite marker position. If light comes on, switch may be defective. Replace switch. Otherwise replace fuse.
	Coils at V1 and V2 not energized.	Poor ground on wire, bad wire connection or damaged wire. Repair as required.
	Marker flow control valve closed too far.	See "Row Marker Speed Adjustment".
Neither marker will raise.	Marker flow control valve closed too far.	See "Row Marker Speed Adjustment".
Right marker will not lower.	Solenoid coil in port V1 not energized.	Check switch on control console. Replace if defective. Check coil ground wire. Check for poor connection or damaged wire.
	Solenoid cartridge in port V1 stuck closed.	Switch cartridge with one on the planter you know is operating properly. If right marker lowers, replace defective cartridge.
Left marker will not lower.	Solenoid coil in port V2 not energized.	Check switch on control console. Replace if defective. Check coil ground wire. Check for poor connection or damaged wire.
	Solenoid cartridge in port V2 stuck closed.	Switch cartridge with one on the planter you know is operating properly. If left marker lowers, replace defective cartridge.
Markers traveling too fast and damaging rubber stop on transport stands and/or	Marker transport stand not adjusted correctly to allow marker cushion cylinders to operate as designed.	See "Row Marker Transport Stand Adjustment".
damaging pivot at rod end of marker cylinders.	Adjust row marker flow control valve.	See "Row Marker Speed Adjustment".

SEED METER (BRUSH-TYPE)

PROBLEM	POSSIBLE CAUSE	SOLUTION
Low count.	Meter RPM too high.	Reduce planting speed.
	Seed sensor not picking up all seeds dropped.	Clean seed tube. Switch meter to different row. If problem stays in same row, replace sensor.
	Lack of lubrication causing seeds not to release from disc properly.	Use graphite or talc as recommended.
	Seed size too large for seed disc being used.	Switch to smaller seed or appropriate seed disc. See "Brush-Type Seed Meter" for proper seed disc for size of seed being used.
	Seed treatment buildup in meter.	Reduce treatment amount used. Thoroughly mix treatment with seed. Add talc.
Low count at low RPM and higher count at higher RPM.	Foreign material lodged in upper brush.	Remove seed disc and remove foreign material from between brush retainer and bristles. Clean thoroughly.
	Worn upper brush.	Replace. See "Brush-Type Seed Meter Maintenance".
Low count at higher RPM and normal count at low RPM.	Seed disc worn in agitation groove area.	Replace disc. Replace. See "Brush-Type Seed Meter Maintenance".
High count.	Seed size too small for seed disc.	Switch to larger or appropriate seed disc.
	Incorrect seed rate transmission setting.	Reset transmission. Refer to rate charts.
	Upper brush too wide (fanned out) for small seed size.	Replace upper brush.
High count. (Milo/Grain Sorghum)	Incorrect brush retainer being used.	Make sure GD8237 brush retainer is used to keep upper brush from fanning out.
Upper brush laid back.	Seed treatment buildup on brush.	Remove brush. Wash with soap and water. Dry thoroughly before reinstalling.
	Foreign material buildup at base of brush.	Remove brush retainer and brush. Clean thoroughly. Reinstall.

VACUUM SEED METER

PROBLEM	POSSIBLE CAUSE	SOLUTION
Low seed count.	Meter RPM too high.	Reduce planting rate or planting speed.
	Singulator blade setting too aggressive.	Adjust singulator blade.
	Vacuum level too low.	Increase fan speed.
	Seed sensor not picking up all seeds dropped.	Clean seed tube. Move meter to different row.
	Seeds sticking to seed disc.	Use graphite or talc to aid release.
	Seed treatment buildup in seed disc recesses.	Reduce amount of treatment used and or mix thoroughly. Add talc.
	Seed size too large for disc used.	Use appropriate disc for seed size.
	Wrong seed disc.	Use appropriate disc for seed type and size.
	Failed/worn drive components.	Inspect and replace parts as required.
	Plugged orifices in seed disc.	Inspect and clean disc. Check remnant ejector.
	Loss of vacuum at meter.	Check for foreign material between vacuum cover and disc. Inspect parts for wear/damage. Clean or replace as required.
	Seed bridging in hopper.	Add graphite to improve seed flow.
	Faulty vacuum gauge reading.	Repair/replace gauge.
	Dirt in vacuum manifold.	Check vacuum manifold for dirt and clean.
	Seed baffle (If applicable) not allowing seed flow due to bridging of seed.	Mix talc thoroughly to coat all seeds. Remove seed baffle. See Row Unit Operation section.
	Seed disc worn.	Replace.
	Vacuum seal worn.	Replace.
Not planting seed.	Seed hoppers empty.	Fill seed hopper.
	Seed tube plugged/damaged.	Clean or replace tube.
	Meter drive damaged.	Repair/replace drive components.
	Low/no vacuum.	Inspect vacuum system and repair as necessary.
	Singulator blade setting too aggressive.	Adjust singulator blade.
	Faulty vacuum gauge.	Repair/replace vacuum gauge.
	Seed bridging in hopper.	Add graphite to improve seed flow.
	Loss of vacuum at meter.	Check for foreign material between vacuum cover and disc. Inspect parts for wear/ damage. Clean and/or replace as required.
	Wrong seed disc.	Use appropriate disc for seed type and size.
	Meter drive clutch not engaged.	Engage drive clutch.
	Fan not running.	Start fan.
	Dirt in vacuum manifold.	Check vacuum manifold for dirt and clean.

VACUUM SEED METER - Continued

PROBLEM	POSSIBLE CAUSE	SOLUTION
Not planting seed. (Continued)	Seed baffle (if applicable) not allowing seed flow due to bridging of seed.	Mix talc thoroughly to coat all seeds. Remove seed baffle. Row Unit Operation section.
	High vacuum.	Adjust vacuum level to appropriate level.
	Wrong seed disc.	Replace seed disc.
	Singulator setting not aggressive enough.	Adjust singulator.
	Faulty vacuum gauge.	Check gauge line for dirt/obstruction. Repair/replace vacuum gauge.
Poor seed spacing.	Obstruction in seed tube.	Clean seed tube.
-	Dirty/damaged seed disc.	Inspect seed disc for damage, foreign material in orifices or seed treatment buildup in recesses. Clean or replace.
	Wrong vacuum setting.	Adjust vacuum to appropriate level.
	Excess foreign material in seed.	Inspect and clean meter and seed discs. Use clean, undamaged seed.
	Incorrect singulator setting.	Adjust singulator to appropriate setting.
	Inconsistent driveline.	Inspect drive components for rust, misalignment, worn or damaged parts. Replace/repair as required.
	Toolbar not level or wrong height.	Adjust hitch to level toolbar and row units.
	Planting too fast for conditions.	Reduce speed.
	Rough field conditions.	Reduce speed.
Irregular seed population.	Driving too fast.	Reduce speed.
Unable to achieve	Tractor hydraulic flow set too low.	Increase flow to fan motor.
desired vacuum level.	Incorrect hydraulic connections.	Check all hydraulic connections and hose routings.
	Damaged fan components.	Inspect motor and impeller for wear/damage and repair/replace as necessary.
	Vacuum hose pinched/kinked/blocked.	Inspect air lines for any damage or obstruction. Clean air lines and manifold by removing end cap from manifold and running fan at high speed.
	Vacuum hose loose/disconnected.	Inspect and reattach all air hoses.
	Tractor not producing required hydraulic flow/ pressure.	Have tractor serviced by qualified technician.
	Dirt in vacuum gauge line.	Check gauge line for dirt/obstruction and clean.

SEED METER (FINGER PICKUP)

PROBLEM	POSSIBLE CAUSE	SOLUTION
One row not planting	Drive release not engaged.	Engage drive release mechanism.
seed.	Foreign material in hopper.	Clean hopper and finger carrier mechanism.
	Seed hopper empty.	Fill seed hopper.
	Row unit drive chain off of sprocket or broken.	Check drive chain.
Unit is skipping.	Foreign material or obstruction in meter.	Clean and inspect.
	Finger holder improperly adjusted.	Adjust to specifications. (22 to 25 in. lbs. rolling torque)
	Broken fingers.	Replace fingers and/or springs as required.
	Planting too slowly.	Increase planting speed to within recommended range.
Planting too many	Planting too fast.	Stay within recommended speed range.
doubles.	Loose finger holder.	Adjust to specifications. (22 to 25 in. lbs. rolling torque)
	Worn brush in carrier plate.	Inspect and replace if necessary.
Overplanting.	Worn carrier plate.	Inspect and replace if necessary.
-	Seed hopper additive being used.	Reduce or eliminate additive or
		increase graphite.
Underplanting.	Seed belt installed backwards.	Remove and install correctly.
	Weak or broken springs.	Replace.
	Spring not properly installed.	Remove finger holder and correct.
	Seed belt catching or dragging.	Replace belt.
	Brush dislodging seed.	Replace brush.
Irregular or incorrect	Driving too fast.	Check chart for correct speed.
seed spacing.	Wrong tire pressure.	Inflate tires to correct air pressure.
	Drive wheels slipping.	Reduce down pressure on row unit down force springs.
	Wrong sprockets.	Check seed rate charts for correct sprocket combinations.
Seed spacing not as	Wrong tire pressure.	Inflate tires to correct air pressure.
indicated in charts.	Inconsistent seed size.	Perform field check and adjust sprockets.
	Wrong sprockets.	Check chart for correct sprocket combination.
	Charts are approximate.	Slight variations due to wear in meter components and tire slippage due to field conditions may produce seed spacing variations.
	Stiff or worn drive chains.	Replace chains.
Scattering of seeds.	Planting too fast.	Reduce planting speed.
, and the second	Seed tube improperly installed.	Check seed tube installation.
	Seed tube worn or damaged.	Replace seed tube.
Seed tubes and/or openers plugging.	Allowing planter to roll backward when lowering.	Lower planter only when tractor is moving forward.
Inconsistent seed depth.	Rough seed bed.	Adjust down pressure springs. Reduce planting speed.
•	Partially plugged seed tube.	Inspect and clean.
	Seed tube improperly installed.	Install properly.

SOLENOID VALVE

PROBLEM	POSSIBLE CAUSE	SOLUTION
No solenoids operate.	Low voltage.	Must be connected to 12 volt DC only. Negative ground.
	Blown fuse.	Replace control console fuse with AGC-15 amp.
	Battery connection.	Clean and tighten.
	Wiring harness damaged.	Repair or replace.
One solenoid valve will not operate.	Bad switch.	Replace on control panel.
	Cut wire in harness.	Locate and repair.
	Bad coil.	Replace.
	Poor connection at coil.	Check.
Valve operating when not energized.	Valve stem stuck open.	Replace cartridge.
	O-ring leaking.	Install new O-ring kit.
	Foreign material under poppet.	Remove and clean cartridge.

TONGUE CYLINDER CIRCUIT

PROBLEM	POSSIBLE CAUSE	SOLUTION
Tongue cylinder will not extend, but will retract.	No power to solenoid valve coil in port V10 and/or V14. Both must be energized.	Check wiring between control console and solenoid coils looking for damaged wires and poor connections.
	Solenoid valve coil defective.	Switch coil from port V13 with V10. If tongue still will not extend, switch coil from V14 with V13. It is not necessary to remove any solenoid wire connections. All three solenoids are normally energized when tongue switch is energized. Replace defective coil.
	Solenoid valve cartridges in port V10 and/ or V14 stuck closed.	Switch cartridge from port V10 with cartridge in port V13. If tongue cylinder retracts, replace defective cartridge from port V10. If problem continues, switch cartridge from port V14 with cartridge in port V13. Replace defective cartridge.
Tongue cylinder will not extend but tongue lock cylinder extends.	Pressure relief valve in port V11 stuck closed or pressure setting too high. (Valve is factory set to open at 1000 PSI.)	Replace or adjust pressure relief valve. To adjust, loosen lock nut and turn counter clockwise to decrease pressure.
Tongue hook does not release before tongue starts to extend.	Solenoid valve cartridge in port V11 stuck open or pressure setting too low. (Valve is factory set to open at 1000 PSI.)	Replace or adjust pressure relief valve. To adjust, loosen lock nut and turn clockwise to increase pressure.
Tongue cylinder will not retract, but will extend.	Solenoid valve coil in port V13 defective.	Switch coil from port V13 with coil from port V14. If coil from port V13 is bad, tongue will extend but not retract. Replace defective coil.
	Solenoid valve cartridge in port V13 stuck closed.	Switch cartridge from port V13 with cartridge from port V14. If cartridge is bad, tongue will extend but not retract. Replace defective cartridge.
Tongue extends with switch off.	Solenoid valve cartridge in port V10 and V14 stuck open.	Replace solenoid valve cartridge.
Tongue retracts with switch off.	Solenoid valve cartridge in port V13 stuck open.	Replace solenoid valve cartridge.
Tongue latch releases. Tongue extends slowly while planting.	Latch cylinder or tongue cylinder leaking internally.	Pressure check latch and tongue cylinders. Repair leaking cylinder(s).

WING LOCK CYLINDER CIRCUIT

PROBLEM	POSSIBLE CAUSE	SOLUTION
Cylinders will not extend or retract.	No power to solenoid valve coils.	Auxiliary switch may be ON. Must be OFF. Check fuse at control console. Replace fuse with 15 amp type AGC if blown. Check for poor wire connection or damaged wire. Repair as required.
Cylinders will not extend.	Solenoid valve coil in port V3 not energized.	Check for power to coil. Check coil ground wire. If OK, switch coil from port V3 with coil from port V4. If cylinders extend but will not retract, replace defective coil.
	Solenoid valve cartridge in port V3 stuck closed.	Switch cartridge in port V3 with cartridge in port V4. If cylinders extend but will not retract, replace defective cartridge.
Cylinders will not retract.	Solenoid valve coil in port V4 not energized.	Check for power to coil. Check coil ground wire. If OK, switch coil from port V4 with coil from port V3. If cylinders retract but will not extend, replace defective coil.
	Solenoid valve cartridge in port V4 stuck closed.	Switch cartridge in port V4 with cartridge in port V3. If cylinders retract but will not extend, replace defective cartridge.
Cylinders retract with switch off.	Solenoid valve cartridge in port V4 stuck open.	Replace solenoid valve cartridge.
Cylinders extend with switch off.	Solenoid valve cartridge in port V3 stuck open.	Replace solenoid valve cartridge.